


Parts Breakdown

Item 13727



Parts Breakdown

Item 13727

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
10124	Plastic Stuffer Spout 10mm for 13727	1	AC992	Stainless Steel Rack for 13727	10	15306	Wheel for 13727	21
10125	Plastic Stuffer Spout 20mm for 13727	2	27637	Gear Block for 13727	11	AC994	Handle for 13727	23
10126	Plastic Stuffer Spout 30mm for 13727	3	15304	Intermediate Shaft for 13727	14	27645	Foot for 13727	28
10127	Plastic Stuffer Spout 40mm for 13727	4	15305	Intermediate Wheel for 13727	15	19959	Thumb Screw for 13727	40
15279	Screw Ring for 13727	5	AC990	Rack to Piston Washer for 13727	16	AC995	Bushes Set for 13727	44
45133	Cylinder for 13727	6	15307	Rack Controlling Shaft for 13727	18	15253	Piston and Gasket for 13727	108
15295	Piston Screw for 13727	7	68745	Shaft with Keys for 13727	19	41906	Air Valve and Spring for 13727	132
15296	Gasket Silicone for 13727	8	15303	Pinion for 13727	20	AC993	Gear Block Complete with Gears and Bushes for 13727	