


Parts Breakdown

Model CE-CN-0025MV 37962




Parts Breakdown

Model CE-CN-0025MV 37962

Item No.	Description	Position	Item No.	Description	Position
AX181	WATER SEALING FOR MICROWAVE 37962	Z40	AX209	SCREW ST3*8PWBHC FOR MICROWAVE 37962, 37963	S02
AX182	GUARD OIL FOR MICROWAVE 37962	Z29	AX210	SCREW CT3*8BBHC FOR MICROWAVE 37962, 37963	S01
AX189	CASE OUT FOR MICROWAVE 37962, 37963	Z24	AX211	HARNESS MAIN FOR MICROWAVE 37962, 37963	L05
AX190	FAN STIRRER FOR MICROWAVE 37962	Z11	AX212	MICROSWITCH MONITOR FOR MICROWAVE 37962, 37963	L04
AX191	HOLDER H.V.C FOR MICROWAVE 37962, 37963	Z01	AX213	MICROSWITCH INTERLOCK FOR MICROWAVE 37962, 37963	L03
AX192	DAMPER FOR MICROWAVE 37962, 37963	W06	AX214	LEVEL SWITCH FOR MICROWAVE 37962, 37963	L02
AX193	MOTOR FAN FOR MICROWAVE 37962, 37963	W03	AX215	BOARD LATCH FOR MICROWAVE 37962, 37963	L01
AX194	FAN FOR MICROWAVE 37962, 37963, 37963	W02	AX216	THERMOSTAT 160°C/95°C FOR MICROWAVE 37962, 37963	E35
AX195	GUIDE FAN FOR MICROWAVE 37962, 37963	W01	AX217	POWER CORD ASSEMBLY FOR MICROWAVE 37962, 37963	E16
AX196	SHAFT STIRRER FOR MICROWAVE 37962	T09	AX218	THERMOSTAT 110°C/70°C FOR MICROWAVE 37962	E40
AX197	MOTOR TRAY FOR MICROWAVE 37962, 37963	T01	AX219	LAMP FOR MICROWAVE 37962	E13
AX198	SPRING WASHER FOR MICROWAVE 37962	S21	AX220	FUSE FOR MICROWAVE 37962, 37963	E11
AX199	SCREW 4*6 FOR MICROWAVE 37962	S18	AX221	FILTER NOISE FOR MICROWAVE 37962, 37963	E10
AX200	SCREW ST3*10PWTHC FOR MICROWAVE 37962	S17	AX222	HIGH VOLTAGE DIODE FOR MICROWAVE 37962, 37963	E07
AX201	SCREW CT4*8TBHC FOR MICROWAVE 37962	S08	AX223	HIGH VOLTAGE CAPACITOR FOR MICROWAVE 37962, 37963	E06
AX202	SCREW CT4*8TBHC FOR MICROWAVE 37962	S07	AX224	HIGH VOLTAGE TRANSFORMER FOR MICROWAVE 37962	E05
AX203	SCREW ST4*20TBHC FOR MICROWAVE 37962	S06	AX225	MAGNETRON FOR MICROWAVE 37962, 37963	E01
AX204	SCREW ST4*12PWBHC FOR MICROWAVE 37962	S05	AX226	HINGE BRACKET ASSEMBLY FOR MICROWAVE 37962, 37963	B03
AX205	SCREW ST4*10TBHC FOR MICROWAVE 37962	S04	AX227	LEG FOR MICROWAVE 37962	B02
AX206	BASE PLANT FOR MICROWAVE 37962	B01	AX228	PRANT COVER FOR MICROWAVE 37962	A09
AX207	ASSEMBLY CAVITY FOR MICROWAVE 37962	A00	AX229	GUIDE WIND FOR MICROWAVE 37962	W04
AX208	SPONGE FOR MICROWAVE 37962	Z22			

Parts Breakdown

Model CE-CN-0025MV 37962



Parts Breakdown

Model CE-CN-0025MV 37962

Item No.	Description	Position	Item No.	Description	Position
AX230	SCREW ST4x30PBHC FOR MICROWAVE 37962	S35	AX240	UPPER HINGE FOR MICROWAVE 37962, 37963	D04
AX231	SCREW ST4x8PBHC FOR MICROWAVE 37962	S03	AX241	LATCH SPRING FOR MICROWAVE 37962, 37963	D03
AX232	HANDLE FOR MICROWAVE 37962, 37963	D14	AX242	LATCH FOR MICROWAVE 37962, 37963	D02
AX233	DOOR DECORATION FOR MICROWAVE 37962	D06	AX243	DOOR FRAME ASSEMBLY FOR MICROWAVE 37962, 37963	D01
AX234	DOOR GASKET FOR MICROWAVE 37962, 37963	D08	AX244	DOOR FOR MICROWAVE 37962, 37963	D00
AX235	DOOR PANEL FOR MICROWAVE 37962, 37963	D07	AX209	SCREW ST3x8PBHC FOR MICROWAVE 37962	S02
AX236	DOOR SCREEN FOR MICROWAVE 37962, 37963	D06	AX246	SEALING RING FOR MICROWAVE 37962, 37963	C50
AX237	DOOR INNER FILM FOR MICROWAVE 37962, 37963	D05	AX247	PCB ASSEMBLY FOR MICROWAVE 37962, 37963	C18
AX238	MEMBRANE SWITCH FOR MICROWAVE 37962, 37963	C17	AX248	CONTROL PANEL FOR MICROWAVE 37962, 37963	C01
AX239	CONTROL PANEL DECORATION FOR MICROWAVE 37962, 37963	C02	AX249	CONTROL PANEL ASSEMBLY FOR MICROWAVE 37962, 37963	C00