



PARTS BREAKDOWN

ITEM	MODEL
39519	JE-ES-0015-F



PARTS BREAKDOWN


ITEM	MODEL
39519	JE-ES-0015-F




PARTS BREAKDOWN

ITEM	MODEL
39519	JE-ES-0015-F

STAINLESS STEEL SELF TAP OPTION



AUTOMATIC SHOWER OPTION



PARTS BREAKDOWN

ITEM	MODEL
39519	JE-ES-0015-F

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
72499	Stainless Steel Basket for 39519	00020	72530	Positioner Lid for 39519	00200	72563	Rustless Screw M6x20 Inox for 39519	00431
72500	Screw H M4x10 Zinc for 39519	00035	64834	Plugging Cap Ø16mm Black for 39519	00212	72564	Rustless Screw M6x12 Inox for 39519	00432
72501	Rustless Washer DIN-9021 D06 for 39519	00040	40594	Rustless Juice Filter Inox for 39519	00217	72565	Rustless Washer Din-6798 D06 Inox for 39519	00436
72502	Screw H M8x30 Zinc for 39519	00048	72532	Luggage-Rack 150x120 for 39519	00219	72692	Traction Disc Feeder for 39519	00480
72503	Turning Feeder Plate for 39519	00055	72533	Gear Feeder 3 Horiz for 39519	00226	72568	Head Feeder for 39519	00485
72504	Cotter H 8x7x15 for 39519	00065	72534	Plastic Lid M4 for 39519	00285	72569	Rustless Feeder Shaft for 39519	00487
72505	Cotter H 8x7x50 for 39519	00066	72535	Plastic Lid M6 for 39519	00286	72570	Feeder Traction Disc Supply for 39519	00488
72506	Rustless Cotter Inox 8x7x70 for 39519	00067	40592	Female Thumbscrew M8 for 39519	00287	72693	C Clip Din-471 E16 for 39519	00489
72507	Screw H M8x25 Zinc for 39519	00072	72537	Male Thumbscrew M6 for 39519	00289	72572	Washer H D28-D06x2 Zinc for 39519	00502
72508	Bearing 6007 for 39519	00083	72538	Feeder Tube Support Clamp for 39519	00311	72573	Rustless Screw M6x10 Inox for 39519	00503
72509	Rustless Screw M4x10 Inox for 39519	00086	72539	Feeder Tube Support MM for 39519	00313	A0263	Magnet for 39519	00509
72510	Blade Rod-Positioner for 39519	00089	72540	Feeder Tube Support MX for 39519	00314	72574	Gear Feeder for 39519	00516
40585	Knife Piece for 39519	00093	AK891	E-Tron Basic-MXM Support for 39519	00320	72580	Rustless Screw M2.9x10 Inox for 39519	00541
71506	Squeezer Male for 39519	00095	72541	Tray 150x120 for 39519	00322	72582	Rustless Screw M5x10 Inox for 39519	00555
40593	Ejector for 39519	00098	72542	Sump Base for 39519	00325	40589	Male Thumbscrew M8 for 39519	00590
72514	Ventilation Grid for 39519	00108	72543	Squeezer Double Drum for 39519	00333	72585	Peel Bucket for 39519	00594
A0259	Magnet Cap for 39519	00167	72545	Sump Grid for 39519	00336	72586	Screw H M10x35 Zinc for 39519	00611
72520	C Clip Din 471 E-34 for 39519	00168	72547	Cover Screen Support Cap for 39519	00348	64837	DC Shower Diffuser for 39519	00660
72521	Washer H D35-D09x3 Zinc for 39519	00171	72550	Juice Tray for 39519	00372	64838	DC Shower Diffuser Cap for 39519	00661
72522	Rustless Washer Din-125 D08 Inox for 39519	00174	72551	Juice Tray (Self) for 39519	00373	64839	DC O-Ring for 39519	00662
72523	Stainless Cotter 8x8x170 Inox for 39519	00176	72552	Feeder Tube Protection for 39519	00395	40587	Rustless Juice Filter Inox for 39519	00675
40590	Male Thumbscrew M8 for 39519	00178	72554	Back Cover MM for 39519	00397	64841	Plugging Cap Ø19mm for 39519	00692
64906	Nut H Zinc M8 for 39519	00188	39696	Cover Screen for 39519	00400	AK893	Tap Handle for 39519	00707
72526	Rustless Wingnut M4 Inox for 39519	00189	72556	Back Cover MX for 39519	00404	64842	Reducer for 39519	00723
72528	Positioner Guide for 39519	00195	72557	Plugging Cap Ø5x12mm for 39519	00408	A0264	DC Valve for 39519	00750

PARTS BREAKDOWN

ITEM	MODEL
39519	JE-ES-0015-F

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
64843	Rustless Screw M2.9x16 Inox for 39519	00752	64861	Tap Spring for 39519	00851	64875	Rustless Screw M2.9x13 Inox for 39519	00882
44090	Rustless Screw Din-85 M4x14 Inox for 39519	00753	64862	Tap Cap for 39519	00852	72614	Feeder Support Kit for 39519	70004
72589	Screw H M6x16 for 39519	00768	64863	Magnet 10-10 for 39519	00854	64876	Self Service Inox Tap Kit for 39519	70008
64845	Rustless Screw M4x16 Inox for 39519	00769	64864	Tap Body for 39519	00855	72615	Feeder Tube Kit MM for 39519	70009
64942	DC Adapter Male 6-1/4" for 39519	00771	64865	Rustless Washer Din-125 D05 Inox for 39519	00856	47164	Squeezing Kit Diameter 45-60mm for 39519	70014
64847	DC Adapter Male 6-1/4" for 39519	00772	64866	Rustless Screw M4x20 Inox for 39519	00857	AP885	Feeder Tube Kit for 39519	70020
64849	DC Elbow 6mm for 39519	00776	64867	Tap Capsule for 39519	00858	72617	Sump Kit for 39519	70026
64851	DC Hose 6mm for 39519	00781	64868	Magnet 10-05 for 39519	00859	64877	Shower Sump Kit for 39519	70027
64853	DC E-Valve Shower Support for 39519	00785	64869	Tap Support for 39519	00860	40586	Positioner Orange Color for 39519	70028
AK894	Plugging Cap for 39519	00821	64950	Tube Det-180 Stainless Steel for 39519	00862	AP886	Reducer Shaft Kit for 39519	70051
64856	Pin Detect D8 for 39519	00836	64871	Tube Det Nut for 39519	00863	AP887	Gear Kit for 39519	70052
64857	Tap Plunger for 39519	00847	64872	Nut H Cro M12x100 for 39519	00864	AP888	Upper Rustless Shaft Kit for 39519	70053
64858	Plunger O-Ring Ø2 for 39519	00848	AK895	Frontal Sheet for 39519	00869	AP889	Lower Rustless Shaft Kit for 39519	70054
64859	Plunger O-Ring Ø4 for 39519	00849	64873	Back Cover for 39519	00878	AP890	Seal Protection Kit for 39519	70055
64860	Tap Handle for 39519	00850	64874	Back Cover for 39519	00880	AP891	Sump Bearing-Lid Kit for 39519	70056