


PARTS BREAKDOWN

| ITEM | MODEL |
|-------|-----------|
| 39687 | Santos 10 |



PARTS BREAKDOWN

| ITEM | MODEL |
|-------|-----------|
| 39687 | Santos 10 |

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|--|----------|----------|---|----------|----------|--|----------|
| 39729 | Complete Lever for 39687 | 10100 | 73120 | Friction Plate for 39687 | 10504 | AM922 | Complete Motor 110V 60Hz for 39687 | 10730B |
| 40683 | Black Lever for 39687 | 10101 | 73121 | Intermediate Flange Only for 39687 | 10505 | AC370 | Complete Rotor with Shaft for 39687 | 10731 |
| 40421 | Lever Axle (Pin) D8x34 for 39687 | 10102 | 73122 | Screw H4x12 for 39687 | 10506 | AM923 | Stator Only 110V 60Hz for 39687 | 10732B |
| 40684 | Complete Cup with Screw and Washer for 39687 | 10103 | 40699 | Complete Friction Clutch for 39687 | 10600 | AC371 | Lower Flange for 39687 | 10741 |
| 40685 | Cup Locking Screw for 39687 | 10104 | 40700 | Friction Clutch & Disc (Welded) for 39687 | 10601 | AC372 | Ondulated Washer for 39687 | 10742 |
| 40686 | Stainless Steel Cup Only for 39687 | 10105 | 40701 | Screw HC M5x10 Stainless Steel for 39687 | 10605 | 73141 | Stainless Steel Housing for 39687 | 10800 |
| 40687 | Stainless Steel Washer for 39687 | 10106 | 40529 | Stainless Steel Driving Pin for 39687 | 10606 | 73143 | Painted Base Only (Grey) for 39687 | 10901 |
| 73114 | Stainless Steel Cover Only for 39687 | 10107 | 40702 | Fiber Pushing Pin for 39687 | 10607 | 40706 | Plastic Drip Tray for 39687 | 10903 |
| 73115 | Stainless Steel Spring for 39687 | 10108 | 40703 | Steel Ball D6 for 39687 | 10608 | 73144 | Bottom Plate for 39687 | 10904 |
| 73116 | Stainless Steel Spring Cap for 39687 | 10109 | 40704 | Brake Stainless Steel Spring for 39687 | 10609 | 40707 | Switch for 39687 | 10905 |
| 73117 | Lever Washer for 39687 | 10110 | 40705 | Complete Drive Plate for 39687 | 10610 | AM924 | On-Off Plate (110V UL) for 39687 | 10906B |
| 40688 | Perforated Strainer (Stainless Steel) for 39687 | 10200 | AC367 | Screw HC M6x8 for 39687 | 10613 | 73147 | Washer 4x10 for 39687 | 10908 |
| 40689 | Complete Stainless Steel Bowl with Nut for 39687 | 10300 | 73125 | Complete Upper Flange for 39687 | 10701 | 73148 | Screw H4x16 ZN for 39687 | 10909 |
| 73118 | Stainless Steel Bowl for 39687 | 10301 | 73126 | Upper Flange for 39687 | 10702 | 73149 | Screw H4x10 for 39687 | 10910 |
| 40690 | Nylon Nut for 39687 | 10304 | 73127 | Bearing 6201 for 39687 | 10703 | 44063 | Power Cord with USA Plug for 39687 | 10912B |
| 40691 | Gasket D12x22x5 for 39687 | 10305 | 73128 | Bearing Washer for 39687 | 10704 | 73151 | Screw 4.8x16 ZN for 39687 | 10913 |
| 40692 | Polyethylene Washer for 39687 | 10306 | 73129 | Screw H4x10 ZN for 39687 | 10705 | 73153 | Screw 4x10 for 39687 | 10917 |
| 40693 | Painted Aluminum Top (Bowl) with 4 Nuts for 39687 | 10400 | 73132 | Bearing 6201 for 39687 | 10712 | 73156 | Screw H M5x12 ZN for 39687 | 10920 |
| 40694 | Painted Aluminum Top Only (Bowl) for 39687 | 10401 | 73134 | Screw H4x10 ZN for 39687 | 10714 | AM925 | Ground Symbol for 39687 | 10922 |
| 40695 | Bowl Locking Nut for 39687 | 10402 | 73135 | Assembling Threaded Rod M5 for 39687 | 10721 | AM926 | Washer AZ 8 for 39687 | 10924 |
| 40696 | Complete Intermediate Flange for 39687 | 10500 | 73136 | Nut H M5 ZN for 39687 | 10722 | AM927 | Nut H M8 ZN for 39687 | 10925 |
| 73119 | Equipped Intermediate Flange without Brushes for 39687 | 10501 | 73137 | Split Washer D5 for 39687 | 10723 | AM928 | Foot (for NSF 110V) for 39687 | 10933 |
| 40697 | Bronze Bearing for 39687 | 10502 | 73138 | Washer AZ 5 for 39687 | 10724 | AM929 | Cap (for 110V) for 39687 | 10934 |
| 40698 | Gasket 12x22x5 for 39687 | 10503 | 73139 | Washer 6x18 for 39687 | 10725 | AM930 | Complete Painted Base NSF 110V for 39687 | 10950B |