


# Parts Breakdown

Model WO-CN-0640 43113



# Parts Breakdown

## Model WO-CN-0640 43113

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AD669	Left Leg for 43113	1	AD682	Door Handle for 43113	14	AD695	Small L Hook for 43113	27
AD670	Right Leg for 43113	2	AD683	Door Handle Insulation Mat 1 for 43113	15	AD696	Large L Hook for 43113	28
AD671	Oven Body for 43113	3	AD684	Door Handle Insulation Mat 2 for 43113	16	AC938	Ash Grill for 43113	29
AD672	Ash Pan for 43113	4	AD685	Side Handle for 43113	17	AC939	Pizza Stone Large for 43113	30
AD673	Ash Pan Support 1 for 43113	5	AD686	Thermometer Holder for 43113	18	46685	PVC Cover Black for 43113	31
AD674	Ash Pan Support 2 for 43113	6	AD687	Thermometer for 43113	19	AC941	Pizza Stone Small for 43113	32
AD675	Chimney for 43113	7	AD688	Caster for 43113	20	AD698	1/4" Flat Washer for 43113	33
AD676	Chimney Cap for 43113	8	AD689	Caster with Brake for 43113	21	AD699	1/4" Spring Washer for 43113	34
AD677	Chimney Exhaust Adjuster for 43113	9	AD690	Pie Server for 43113	22	AD700	1/4" Bolt for 43113	35
AD678	Chimney Base for 43113	10	AD691	Pizza Cutter for 43113	23	AD701	Screw Set for 43113	36 - 38
AD679	Bottom Plate for 43113	11	AD692	Brush for 43113	24	AJ381	Complete Door Assembly for 43113	
AD680	Door for 43113	12	AD693	Pizza Peel for 43113	25			
AD681	Door Handle Brace for 43113	13	AD694	S Hook for 43113	26			