


Parts Breakdown

Model RS-CN-0550 44474



Parts Breakdown

Model RS-CN-0550 44474

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
68944	Upper Hinge Fixing Plate for 44474	1	69046	Bottom Plate for 44474	22	68979	Door Pin Support Cover for 44474	40
69006	Top Cover Plate for 44474	2	68966	Casters with Brake for 44474	23	60534	Compressor for 44474	41
69007	Evaporator Holder for 44474	3	68967	Casters for 44474	24	60948	Water Receiver for 44474	42
69008	Evaporator Polystyrene for 44474	4	68968	Casters Pad for 44474	25	79319	Dry Filter for 44474	43
69009	Upper Box Polystyrene for 44474	5	69025	Front Panel for 44474	26	68341	Motor for 44474	44
68949	Ventilation Tuyere for 44474	6	68970	Thermostat Bracket for 44474	27	60932	Flange for 44474	45
69010	Upper Box Baffle for 44474	7	60521	Display Label for 44474	28	60933	Fan Blade of Condenser for 44474	46
68951	Upper Box Baffle Connector for 44474	8	68971	Main Circuit Board for 44474	29-1	60934	Condenser for 44474	47
69011	Fence Frame for 44474	9	68972	Defrost Probe for 44474	29-2	68983	Evaporator for 44474	48
70107	Clips for 44474	10	60725	Temperature Probe for 44474	29-3	68984	Fan Motor Bracket for 44474	49
69012	Back Glass for 44474	11	60581	High Temperature Probe for 44474	29-4	68985	Fan Motor for 44474	50
69013	Side Glass for 44474	12	71514	Switch for 44474	30	68986	Bottom Door Frame Fixing Plate for 44474	51
69014	Door Glass for 44474	13	69027	Base Nets for 44474	31	69031	Bottom Door Frame for 44474	52
69038	Back Pillar for 44474	14	68974	Power Cord for 44474	32	60529	Door Frame Square Connector (Small Angle) for 44474	53
69039	Front Left Pillar for 44474	15	79291	Wire Clip for 44474	33	69032	Around the Door Frame for 44474	54
69045	LED Lights for 44474	16	61167	Circuit Board Box for 44474	34	69033	Door Seal for 44474	55
69018	Front Left Pillar Garnish for 44474	17	60594	Cover of Circuit Board Box for 44474	35	60525	Door Frame Square Connector (Big Angle) for 44474	56
69020	Front Right Pillar Garnish for 44474	18	68975	Door Pin Support for 44474	36	69034	Upper Door Frame for 44474	57
69042	Front Right Pillar for 44474	19	68976	Pulley Support for 44474	37	60570	Upper Door Frame Fastener for 44474	58
69022	Box Chassis for 44474	20	68977	Door Pulley for 44474	38	67652	LED Transformer for 44474	59
69023	Box Support Frame for 44474	21	68978	Door Pin Support Pad for 44474	39	60572	Temperature Display for 44474	60