



# Parts Breakdown

Model BS-VE-3200-SS 45979



# Parts Breakdown

Model BS-VE-3200-SS 45979




# Parts Breakdown

---


Model *BS-VE-3200-SS* 45979

# 60139



# Parts Breakdown

Model **BS-VE-3200-SS** 45979




# Parts Breakdown

---

Model *BS-VE-3200-SS* 45979

# 60281




# Parts Breakdown

---

Model *BS-VE-3200-SS* 45979


## 60108



# Parts Breakdown

---

Model **BS-VE-3200-SS** 45979



60171







# Parts Breakdown

---


Model **BS-VE-3200-SS** 45979



60291



60275



60299

# Parts Breakdown

## Model BS-VE-3200-SS 45979

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
62061	Long Door Hinge for 45979	60014	AO952	Aluminum Guide for 45979	60117	40168	Seal Model 30 to 36 for 45979	60217
AO935	Collection Tray for 45979	60026AT	64594	Nylon Guide for 45979	60120	64566	Aluminum Support for 45979	60222
AO936	Collection Tray for 45979	60028HI	64586	Fork for 45979	60122	64574	Flywheel Front Cover for 45979	60230
AO937	Base with Steel or Iron Facial Roller for 45979	60029AT	64578	Cleaning Strap for 45979	60125	AO964	Front Cover for Steering Wheel for 45979	60230AT
AO938	Iron Base for Motor for 45979	60031AT	64579	Scraper for 45979	60126	AO965	Hinge for 45979	60245
AO939	Iron Base for Motor for 45979	60035HI	AO953	Single Handle for 45979	60128AT	AO966	Sealed Steering Wheel Cover for 45979	60246AT
AO940	Belt for 45979	60060	AO954	Single Handle for 45979	60130HI	64570	Tension Screw for 45979	60249
64592	Upper Steel Guide for 45979	60061	AO955	Complete Box + Start & Stop Button for 45979	60134	AO967	Back Cover for Waiter for 45979	60251AT
62184	Spacer for 45979	60062	17710	Clip for 45979	60139	AO968	Green Button for 45979	60253
64583	Lower Shaft of Mozo for 45979	60065	AO956	Iron Pin for 45979	60141AT	AO969	Red Button for 45979	60254
AO941	Cart Wheel Axle for 45979	60075AT	AO957	Iron Pin for 45979	60143HI	62143	Screw for Roller Port Guide for 45979	60255
AO942	Switch for 45979	60076	64571	Front Knob for 45979	60151	AJ915	Screw for 45979	60257
AO943	Cart Wheel Axle for 45979	60079HI	16869	Knob for 45979	60153	62197	Complete Car Iron Wheel for 45979	60259
AO944	Upper Steering Wheel Axle for 45979	60083	64569	Front Platinum for 45979	60160	AO970	Graduation Screw for Top Steering Wheel for 45979	60263
AO945	Iron Squares for 45979	60086AT	AO958	Plate to Hold the Steering Wheel Wiper for 45979	60163	AO971	Screw to Tension the Motor for 45979	60269AT
AO946	Micro Switch for 45979	60089	62203	Motor Pulley for 45979	60169	64564	Lower Flywheel for 45979	60275
AO947	Iron Squares for 45979	60090	61399	Roller Door for Complete Guide for 45979	60171	AO972	Screw to Tension the Motor for 45979	60278
AO948	Aluminum Flank for 45979	60098T.AT	64190	Complete Guide Door for 45979	60172	AO973	Upper Flywheel with Built-in Axle for 45979	60281
AO949	Aluminum Flank for 45979	60099T.HI	AO959	Tape Protector for 45979	60174	64577	Upper Flywheel for 45979	60291
62066	Aluminum Front for 45979	60105	62173	Motor Tension Screw for 45979	60189	64580	Trapezoidal Flywheel for 45979	60299
AO950	Full Front for 45979	60108	AO960	Seal for Upper Shaft for 45979	60192	62151	Motor Base Rubber for 45979	60300
64563	Door Hook for 45979	60112	AO961	Seal for Upper Shaft for 45979	60193	AJ570	Rubber Stopper for 45979	60301
15587	Fluted Guide Model for 45979	60113	AO962	6200 Belt Roller for 45979	60203	AO974	Base with Steel or Iron Facial Roller for 45979	60317HI
AO951	Grooved Guide for Fork for 45979	60114HI	AO963	Roller Bearing 6206 for Upper Steering Wheel for 45979	60205	AO975	Push Button Case Only for 45979	60353
64593	Lower Steel Guide for 45979	60115	64815	Complete Grooved Wheel for 45979	60208			
64592	Upper Steel Guide for 45979	60116	62194	Complete Flat Wheel for 45979	60212			