





Parts Breakdown

Model CD-GR-1500 46321





Parts Breakdown

Model CD-GR-1500 46321




Parts Breakdown

Model CD-GR-1500 46321






Parts Breakdown

Model CD-GR-1500 46321




Parts Breakdown

Model CD-GR-1500 46321





Parts Breakdown

Model CD-GR-1500 46321





Parts Breakdown

Model CD-GR-1500 46321





Parts Breakdown

Model CD-GR-1500 46321





Parts Breakdown

Model CD-GR-1500 46321






Parts Breakdown

Model CD-GR-1500 46321





Parts Breakdown

Model CD-GR-1500 46321




Parts Breakdown

Model CD-GR-1500 46321



Parts Breakdown

Model CD-GR-1500 46321



Parts Breakdown

Model CD-GR-1500 46321

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
73794	Filter Retaining Nut for 46321	001.00.00017	AE408	Control Panel - Steel Base for 46321	001.15.00155	AE421	Hose Black (1/4)6x12 L: 560mm T Connector D10-D6 - Pressure Gauge (Hose not Visible) for 46321	002.00.00132-T2
73825	Inox Screw 2.9x10 for 46321	001.00.00073	AE409	Front Cover A1510 for 46321	001.15.00156	73831	Lock Washer Inox 4 for 46321	002.00.00140
73833	Nut M10 Inox for 46321	001.00.00093	AE410	Inox Base for Draining Pump for 46321	001.15.00169	41139	Rinse Pipe Retaining Nut for 46321	002.00.00144
73774	Domed Cap Nut M6 for 46321	001.00.00110	AE411	Plastic Handle Spacer for 46321	001.15.00182	73763	Cap for Rinse Arm VE-KN-1500 for 46321	002.00.00145
AE405	Lock Washer D4 for 46321	001.00.00162	AE412	Electrical Components Panel 1510 for 46321	001.15.00191	60978	O-Ring 45x6 for 46321	002.00.00150
73800	Galvanized Lock Washer 6.4x11x0.7 for 46321	001.00.00204	AE413	Electrical Components Box Cover 1510 for 46321	001.15.00192	AE422	Nut M10 Galvanised for 46321	002.00.00151
61020	Front Cover Screw Inox M6x25mm for 46321	001.00.00247	41137	Inox Nipple 1/2" for 46321	002.00.00030	AD905	Lock Washer M4 for 46321	002.00.00162
61024	Leveling Feet 1 3/4 304 145/210 M10x25 (NSF) for 46321	001.00.00256	73780	Drain and Over Flow Base Nut 1 1/2 for 46321	002.00.00037	73871	Teflon 12-6-2 for 46321	002.00.00169
AD882	Washer D4x10 for 46321	001.00.00280	AE414	Nut M4 Galvanised for 46321	002.00.00046	61006	Balance F15x20 for 46321	002.00.00195
AE406	Bracket for Pressure Gauge 1510 for 46321	001.00.00304	73766	Clamp 40-60 for 46321	002.00.00050	AD906	Fittings 1/4x7 Fem. for 46321	002.00.00198
AD884	Bracket for Peristaltic Pumps for 46321	001.12.00033	73768	Clamp 60-80 for 46321	002.00.00051	73861	Rubber Gasket 109x54x3 for 46321	002.00.00223
73752	Back Cover 1500 for 46321	001.15.00001	61019	Clamp 10-16 for 46321	002.00.00052	41136	Inox Angle Male/Female 1/2" for 46321	002.00.00226
73793	Filter Element for 46321	001.15.00012	73841	Nut 1/2 for 46321	002.00.00062	61018	Clamp 8-12 for 46321	002.00.00231
73776	Door Handle 1500 for 46321	001.15.00029	73856	Rinse Base TUR - KN for 46321	002.00.00083	73773	Detergent Tank Injector for 46321	002.00.00233
73812	Inox Bolt M8x70 for 46321	001.15.00036	73821	Inox Nut M3 for 46321	002.00.00090	61007	Filter Plastic for Rinse Aid Valve for 46321	002.00.00242
41122	Door Spring Turbo 1500 for 46321	001.15.00037	41140	O-Ring 10.5x3 for 46321	002.00.00091	60376	Elbow Draining Pipe OD22-ID19mm 1.5 for 46321	002.00.00265
73853	Pump Filter Turbo 1500 for 46321	001.15.00078	60952	Inox Nut M4 for 46321	002.00.00095	60981	Pressure Gauge 2" 0/60 PSI 1/4 NPT (NSF Approved) for 46321	002.00.00286
73832	Lower Back Cover 1500 for 46321	001.15.00082	73749	O-Ring 20x4 for 46321	002.00.00097	AE423	Nut M5 Galv for 46321	002.00.00296
73805	Hood Support Pipe 30x1100 for 46321	001.15.00084	AE415	O-Ring 48x4 for 46321	002.00.00102	65670	PRV Valve for 46321	002.00.00307
73864	Support for Filter Mid for 46321	001.15.00094	64817	Inlet Hose 1500mm 10x14.5 Hot Water Straight/Elbow with Gasket for 46321	002.00.00109	65669	T-Connection Boiler 10 - 6 for 46321	002.00.00308
73863	Support for Filter Back for 46321	001.15.00095	73822	Inox Nut M8 for 46321	002.00.00117	AE424	Pressure Hose 20x30 for 46321	002.00.00317
73779	Door Handle to Hood Connector for 46321	001.15.00100	AE416	Hose Black (3/8)10x16.5 L: 780mm Boiler - DVGW Valve for 46321	002.00.00119-T1	41085	Sprayer for Rinsing Arm for 46321	002.11.00008
61046	Basket Support for 46321	001.15.00113	AE417	Hose Black (3/8)10x16.5 L: 1110mm Water Valve - DVGW Valve for 46321	002.00.00119-T2	AE425	Angle F/F 1" D35 for 46321	002.12.00009
73865	Support Plate for Pressostat for 46321	001.15.00131	AE418	Hose Black (3/8)10x16.5 L: 360mm Boiler - Machine Tank for 46321	002.00.00119-T3	AE426	Thread Nipple 1" L35 for 46321	002.12.00011
AE407	Spacer D12/10x23 for 46321	001.15.00145-1	AE419	Hose Black (3/8)10x16.5 L: 500mm Water Valve -T Connector D10-D10 for 46321	002.00.00119-T4	AE427	Gasket 1" for 46321	002.12.00012
61036	Boiler Turbo for 46321	001.15.00148	41106	Wash Pump Inlet Hose for 46321	002.00.00127	AE428	Washer D55x35 for 46321	002.12.00013
61044	Inox Knob for Sqare Tank Filter for 46321	001.15.00153	AE420	Hose Black (1/4)6x12 L: 630mm T Connector D10-D6 - Rinse Pump (Hose not Visible) for 46321	002.00.00132-T1	AE429	Nut 1" for 46321	002.12.00014

Parts Breakdown

Model CD-GR-1500 46321

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
73755	Base for Tank Filter Turbo 1500 for 46321	002.15.00012	60968	Cable Rubber Protector for 46321	003.00.00025	73838	Micro Relay 8 Pins Faston for 46321	003.00.00306
41132	Drain and Overflow Base for 46321	002.15.00017	41090	Pressostat Switch for 46321	003.00.00033	73829	Inox Tapping Screw 4.2x13 for 46321	003.00.00309
61040	Retaining Plate Turbo 1500 for 46321	002.15.00024	73843	Nut M6 Galvanised for 46321	003.00.00041	73772	Copler 8x31 for 46321	003.00.00323
AE430	Retaining Plate for Filter for 46321	002.15.00025	73834	M4 Nut Galvanised for 46321	003.00.00046	73869	Tapping Screw 4.8x13 for 46321	003.00.00346
73855	Pump Output Hose for 46321	002.15.00029	41119	Relay Magnetic Contactor for 46321	003.00.00056	AE437	Rubber Cable Protection N.01 for 46321	003.00.00347
41131	Drain and Overflow Pipe for 46321	002.15.00031	60957	Galv. Nut M3 for 46321	003.00.00065	AD932	Hex Bolt M6x12 Galvanised for 46321	003.00.00355
73847	Plastic Guide D.30 for 46321	002.15.00044	73852	Pump 1.5 HP 208-240V 6 2P UL for 46321	003.00.00079	AD933	Plastic Basket 500x000 for Glasses for 46321	003.00.00390
73808	Inox Axle Bolt Short M8x17 for 46321	002.15.00052	73878	Threaded Shaft M4x60 for 46321	003.00.00086	73803	Heating Element Nut 13mm M4-M6 for 46321	003.00.00431
73807	Inox Axle Bolt Long M8x35 for 46321	002.15.00053	73816	Inox Hex Bolt M6x20 for 46321	003.00.00104	AD934	Plastic Cutlery Quadrato for 46321	003.00.00439
73854	Pump Inlet Hose for 46321	002.15.00058	60310	Detergent Inlet Tube 4x6mm (Transparent) for 46321	003.00.00140	73815	Inox Hex Bolt M4x60 for 46321	003.00.00441
73872	Teflon Washer D16xD8x1mm for 46321	002.15.00074	AE433	Tubo Transparent 4x6 L: 2500mm for 46321	003.00.00140-1	60973	Pipe Rubber Protector for 46321	003.00.00466
61048	Tank Filter Base Rubber Gasket Turbo 1500 for 46321	002.15.00075	AE434	Tubo Transparent 4x6 L: 1160mm for 46321	003.00.00140-2	60311	Rinse Aid Inlet Tube 4x6mm (Blue) for 46321	003.00.00487
73882	Wash Supply Inox Turbo for 46321	002.15.00080	AD925	Water Input Valve Double for 46321	003.00.00151	73884	Washer Steel 6x18 for 46321	003.00.00516
AE431	Rinsing Arm A and B for 46321	002.15.00081-A-B	AD927	Plast.Basket 50x50 for 46321	003.00.00166	41133	Terminal Block 16mm for 46321	003.00.00534
73806	Inox Axle 20 8 Turbo 1500 EVO for 46321	002.15.00082	41087	Tank Thermofuse 90C for 46321	003.00.00168	AE438	Plastic Grip D25 for 46321	003.00.00538
41124	Wash and Rinse Group Retaining Nut 25 7 8 for 46321	002.15.00083	41088	Boiler Thermofuse 105C for 46321	003.00.00180	73867	Tank Heating Element Retaining Bracket for 46321	003.00.00570
41126	Wash and Rinse Base Lower Plastic for 46321	002.15.00084	41113	Tank Draining Pump/Motor 230V-65Watt for 46321	003.00.00184	61037	Heater Element Boiler 1500, 7.5kW for 46321	003.00.00575
41123	Rinsing and Washing Arms Cross Plastic for 46321	002.15.00085	AD928	Terminal Block Support for 46321	003.00.00198-4	73827	Inox Screw M4x10 for 46321	003.00.00579
41125	Wash and Rinse Base Upper Plastic for 46321	002.15.00086	60959	Tapping Screw 3.5x9.5 for 46321	003.00.00200	73820	Inox Machine Screw M4x10 for 46321	003.00.00580
73845	Pipes Turbo 1500 Inox 30x1x248 for 46321	002.15.00089	73883	Washer Inox 6x18 for 46321	003.00.00221	AE439	Inox Screw M3x10 for 46321	003.00.00581
73858	Rinse Supply Inox Turbo for 46321	002.15.00090	61045	Inox Hex Screw M6x12 for 46321	003.00.00242	AE440	Magnetic Contactor for 230TF 7.5kW for 46321	003.00.00606
61038	Wash and Rinse Cross Turbo Complete for 46321	002.15.00091	AD929	Clamp 20-32 for 46321	003.00.00244	AD935	Atlas Main Board Version for 46321	003.00.00607
73795	Flow Control Disc for Base for 46321	002.15.00103	73758	Boiler Element Fitting Base for 46321	003.00.00260	AD936	User Interface 7 Segm. Display Version for 46321	003.00.00609
AE432	Reducing D40-25 for Drain Pump 1510 for 46321	002.15.00106	73839	Non Return Valve (DVGW) for 46321	003.00.00269	AD939	Electromagnetic Filter 250V 50/60Hz 10A for 46321	003.00.00625
41127	Teflon 18x10 for 46321	002.35.00026	73811	Inox Bolt M10x64 Allen for 46321	003.00.00274	AD940	Spacer Plastic PCB RC-14 for 46321	003.00.00630
AD916	T-Connector D10-D10 for 46321	002.51.00007	60969	Galv. Bolt M4x10 for 46321	003.00.00278	AD941	Box Plastic 100x100x70 for 46321	003.00.00631
73802	Heater Element Cover for 46321	003.00.00004	AE435	Power Supply Board 6con. for 46321	003.00.0030	AD942	PCU Spacer 3.4x6x5 for 46321	003.00.00659
41091	Pressostat Chamber for 46321	003.00.00014	AE436	Nut M8 Galv. for 46321	003.00.00301	AD943	Peristaltic Detergent Pump Seko for 46321	003.00.00684

Parts Breakdown

Model CD-GR-1500 46321

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AD944	Peristaltic Rinse Aid Pump Seko for 46321	003.00.00687	AE442	Power Switch On-Off Comeloux for 46321	003.15.00010	AE445	Boiler Complete 1500 NSF for 46321	006.15.00017
AD947	Magnetic Unit D17x4 for 46321	003.00.00731	41128	Tank Heating Element C1500 6kW for 46321	003.15.00095	AE446	Electrical Box (UL/ETL) for 46321	006.15.00018
AD948	Magnetic Sensor (UL Type) for 46321	003.00.00732	AE443	Film for A1510 (LCD) for 46321	003.15.00117	AE447	Electrical Box for Power Supply A1510 for 46321	006.15.00019
AD950	Detergent & Rinse-Aid Pump Kit for 46321	003.00.00734	AE444	Control Panel Complete A1510/NSF for 46321	003.15.00124			
AE441	Tank Draining Pump Kit for 46321	003.00.00736	61034	Boiler 1500 400V Complete (1 Heating Elements) for 46321	006.15.00008			