


Parts Breakdown

Model FW-CN-0533-B 46572



Parts Breakdown

Model FW-CN-0533-B 46572

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
27147	Plastic Plug for 46572	1	37129	Lamp Socket for 46572	9	72750	Internal Wire for 46572	17
AC774	Upper Frame for 46572	2	72745	M3 Screw for 46572	10	72751	Heat Shrinkable Tube for 46572	18
27148	On/Off Switch for 46572	3	27874	Bulb (250W Max) Clear for 46572	11	72752	M4 Screw for 46572	19
AC775	Middle Frame for 46572	4	27181	*Food Tray for 46572	12	72753	Ground Screw for 46572	20
AC776	Lamp Shade for 46572	5	AC777	Base Tube for 46572	13	72754	Cord Grip for 46572	21
72742	Insulation Board for 46572	6	72747	Nut for 46572	14	72755	Power Cord for 46572	22
72743	Insulation Paper for 46572	7	27150	Thumb Screw for 46572	15	72756	Plug for 46572	23
72744	M5 Screw for 46572	8	72749	Plastic Pad for 46572	16			

*** Food Tray not included**