


PARTS BREAKDOWN

ITEM	MODEL
47718	VP-IT-0300



PARTS BREAKDOWN

ITEM	MODEL
47718	VP-IT-0300

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
A0021	Body for 47718	1	A0028	Seal Switch for 47718	11	A0038	Green Wiring for 47718	21
A0022	Base for 47718	2	A0029	Welding LEDs for 47718	13	A0039	Black Wiring for 47718	21
A0023	Cover for 47718	3	A0030	Green LED for 47718	14	A0040	Cable/Plug for 47718	22
A0024	Lower Vacuum Chamber for 47718	4	A0031	Vacuum Pump for 47718	15	A0041	Hinges with Screws for 47718	23
A0025	Upper Vacuum Chamber for 47718	5	A0032	Pump Base for 47718	16	A0042	Vacuum Socket for 47718	24
41618	Sealing Bar Complete for 47718	6	A0033	Solenoid Valve for 47718	17	A0043	Screw Rivet for 47718	25
72249	Top Bar for 47718	7	A0034	Electronic Board for 47718	18	A0044	Cover Screws for 47718	26
72246	Gasket for 47718	8	A0035	Filter Socket with Fuse for 47718	19	A0045	Base Feet for 47718	27
A0026	Vacuum Gauge for 47718	9	A0036	N Series Hose Set for 47718	20			
A0027	Start/Stop Switch for 47718	10	A0037	NF Series External Filter for 47718	20			