




PARTS BREAKDOWN

ITEM	MODEL	SERIAL NUMBER
48145	PE-IT-0120-R-RB	000001 - 999999



PARTS BREAKDOWN

ITEM	MODEL	SERIAL NUMBER
48145	PE-IT-0120-R-RB	000001 - 999999



PARTS BREAKDOWN

ITEM	MODEL	SERIAL NUMBER
48145	PE-IT-0120-R-RB	000001 - 999999

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AR325	RED ILLUMINATED BIPOLAR SWITCH 0-I FOR 48145	R10	AR305	DRIVER CONTROL PANEL CONNECTION CABLES FOR 48145	R167	AR302	CONTROL PANEL DRIVER 115V FOR 48145	R1611
AR301	RECIRCULATION TEMPERATURE THERMOCOUPLE FOR 48145	R88	AR322	SPEED SELECTOR FOR 48145	R168	AR311	VOLTAGE FILTER SCHAFFNER 115V FOR 48145	R1631
AR300	OVEN TEMPERATURE THERMOCOUPLE FOR 48145	R89	AR319	COMPLETE "START COOKING" BUTTON FOR 48145	R169	AR324	SET RELAY 115V FOR 48145	R1641
AR327	GREEN SELECTOR 0-I FOR 48145	R126	AR307	SCREEN LABEL CONTROL PANEL KROM FOR 48145	R172	AR306	DRIVER 115V FOR 48145	R1651
AR317	REFRACTORY HOB Ø120 FOR 48145	R151	AR316	CONTROL PANEL SWITCH KIT KROM FOR 48145	R173	AR320	COMMAND PANEL KROM 115V FOR 48145	R1701
AR318	REFRACTORY HOB Ø140 FOR 48145	R152	AR310	COMPLETE EMERGENCY SELECTOR FOR 48145	R176	AR328	COMMAND COVER KROM 115V FOR 48145	R1711
AR323	BRUSHES / SCRAPERS SET FOR 48145	R153	AR326	POTENTIOMETER RHS2 FOR 48145	R177	AR309	COOKING TIMER 115V FOR 48145	R1741
AR321	AXIAL BEARING FOR 48145	R154	AR330	SPEED VARIATOR RHS FOR 48145	R178	AR308	DIGITAL THERMOMETER 2115V FOR 48145	R1751
AR303	FAN CONNECTION CABLE RHS-DRIVER FOR 48145	R158	AR313	ROTATION MOTOR 115V FOR 48145	R1551	AR329	POSITION PIPE 270 TC 350 FOR 48145	V822
AR314	COMPLETE GENERAL SWITCH FOR 48145	R162	AR304	MOTOR CONNECTION CABLE TO DRIVER 115V FOR 48145	R1561			
AR315	DRIVER PANEL CONNECTOR SET FOR 48145	R166	AR312	RECIRCULATION FAN 115V FOR 48145	R1571			