


Parts Breakdown

Model CE-CN-10370H 48587



Item No.	Description	Position
AX150	BIG HANDLE FOR PANINI GRILL 48587	1
AX151	GRILLING PLATE(TOP) FOR PANINI GRILL 48587	2
AX152	GRILLING PLATE(BOTTOM) FOR PANINI GRILL 48587	3
AX153	SMALL HANDLE FOR PANINI GRILL 48587, 48588	4
AX154	OIL BUCKET FOR PANINI GRILL 48587, 48588	5
AX155	COPPER PILLAR FOR PANINI GRILL 48587	6
AX156	SWITCH FOR PANINI GRILL 48587, 48588	7
AX157	KNOB FOR PANINI GRILL 48587, 48588	8
AX158	DIGITAL TEMERTURED DISPLAY FOR PANINI GRILL 48587, 48588	9
AX159	INDICATOR LIGHT FOR PANINI GRILL 48587, 48588	10
AX160	THERMOSTAT FOR PANINI GRILL 48587, 48588	11

Item No.	Description	Position
AX161	FOOT FOR PANINI GRILL 48587, 48588	12
AX162	NUT FOR PANINI GRILL 48587, 48588	13
AX163	METAL GASKET FOR PANINI GRILL 48587, 48588	14
AX164	SILICONE GASKET FOR PANINI GRILL 48587, 48588	15
AX165	SIDE PULL CODE FOR PANINI GRILL 48587, 48588	16
AX166	HANDRAIL FOR PANINI GRILL 48587, 48588	17
AX167	TOP ELEMENT FOR PANINI GRILL 48587	18
AX168	COPPER BLOCK FOR PANINI GRILL 48587	19
AX169	COVER FOR PANINI GRILL 48587	20
AX170	BOTTOM ELEMENT FOR PANINI GRILL 48587	21