


Parts Breakdown

Model CE-CN-10173LH 48588



Item No.	Description	Position	Item No.	Description	Position
AX171	BIG HANDLE FOR PANINI GRILL 48588	1	AX165	SIDE PULL CODE FOR PANINI GRILL 48587, 48588	13
AX153	SMALL HANDLE FOR PANINI GRILL 48587, 48588	2	AX175	COPPER BLOCK FOR PANINI GRILL 48588	14
AX172	ELEMENT FOR PANINI GRILL 48588	3	AX166	HANDRAIL FOR PANINI GRILL 48587, 48588	15
AX154	OIL BUCKET FOR PANINI GRILL 48587, 48588	4	AX176	POWER LINE FOR PANINI GRILL 48588	16
AX156	SWITCH FOR PANINI GRILL 48587, 48588	5	AX177	TOP COVER FOR PANINI GRILL 48588	17
AX159	INDICATOR LIGHT FOR PANINI GRILL 48587, 48588	6	AX178	TOP BAKING BOARD FOR PANINI GRILL 48588	18
AX158	DIGITAL TEMERTURED DISPLAY FOR PANINI GRILL 48587, 48588	7	AX179	LOWER GRILL BOARD FOR PANINI GRILL 48588	19
AX157	KNOB FOR PANINI GRILL 48587, 48588	8	AX180	TEMPERATURE LIMITER FOR PANINI GRILL 48588	20
AX160	THERMOSTAT FOR PANINI GRILL 48587, 48588	9	AX162	NUT FOR PANINI GRILL 48587, 48588	21
AX161	FOOT FOR PANINI GRILL 48587, 48588	10	AX163	METAL GASKET FOR PANINI GRILL 48587, 48588	22
AX173	COVER FOR PANINI GRILL 48588	11	AX164	SILICONE GASKET FOR PANINI GRILL 48587, 48588	23
AX174	BELOW ELEMENT FOR PANINI GRILL 48588	12			