


# Parts Breakdown

**Model BS-CN-2400-S** 48787



# Parts Breakdown

## Model BS-CN-2400-S 48787

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AQ318	Cover Plate for 48787	1	AQ343	Angle Block for 48787	26	AQ368	Support Plate for 48787	51
AQ319	Handle for 48787	2	AQ344	Guiding Shaft for 48787	27	AQ369	Saw for 48787	52
AQ320	Sliding Countertops for 48787	3	AQ345	Guide Plate for 48787	28	AQ370	Motor for 48787	53
AQ321	Lock Ring Axis for 48787	4	AQ346	Guiding Shaft (Circle) for 48787	29	AQ371	Meat Scraper Seat for 48787	54
AQ322	Lock Ring Plate for 48787	5	AQ347	Sliding Square Track for 48787	30	AQ372	Meat Scraper for 48787	55
AQ323	Knob for 48787	6	AQ348	Mobile Protective Cover for 48787	31	AQ373	Handle for 48787	56
AQ324	Table-Board for 48787	7	AQ349	Manger Board for 48787	32	AQ374	Skeleton Oil Seal for 48787	57
AQ325	Sliding Countertops Axis for 48787	8	AQ350	Pressure Spring for 48787	33	AQ375	Waterproof Flange for 48787	58
AQ326	Back Frame for 48787	9	AQ351	Belt Wheel 1 for 48787	34	AQ376	Belt Wheel 2 for 48787	59
AQ327	Cover for 48787	10	AQ352	Oil Seal for 48787	35	AQ377	Washer for 48787	60
AQ328	Adjusting Handle for 48787	11	AQ353	Axis for 48787	36	AQ378	Baseboard for 48787	61
AQ329	Spring for 48787	12	AQ354	Spacer for 48787	37	AQ379	Angle Steel for 48787	62
AQ330	End Cover for 48787	13	AQ355	Bearing for 48787	38	AQ380	Electrical Box for 48787	63
AQ331	Sheath for 48787	14	AQ356	O-Rings for 48787	39	AQ381	Micro Switch for 48787	64
AQ332	Mandrel for 48787	15	AQ357	Gland 1 for 48787	40	AQ382	Micro Switch Bracket for 48787	65
AQ333	Spring for 48787	16	AQ358	Door Closure for 48787	41	AQ383	Control Button for 48787	66
AQ334	Tension Guide Bush for 48787	17	AQ359	Spindle for 48787	42	AQ384	Side Panel 2 for 48787	67
AQ335	Hanging Block for 48787	18	AQ360	Protect Tooth Holder for 48787	43	AQ385	Seat with Drawer for 48787	68
AQ336	Black Cover for 48787	19	AQ361	Protect Tooth Plate for 48787	44	AQ386	Front Side Panel for 48787	69
AQ337	Sliding Shaft for 48787	20	AQ362	Handle for 48787	45	AQ387	Drawer for 48787	70
AQ338	Slider for 48787	21	AQ363	Angle Iron Right for 48787	46	AQ388	Undercover for 48787	71
AQ339	Body for 48787	22	AQ364	Angle Iron for 48787	47	AQ389	Baseboard for 48787	72
AQ340	Holder for 48787	23	AQ365	Nylon Block for 48787	48	AQ390	Mat for 48787	73
AQ341	Cleaning Shell for 48787	24	AQ366	Guide Block (Square) for 48787	49			
AQ342	Clean Sheet for 48787	25	AQ367	Table-Board Support for 48787	50			