



PARTS BREAKDOWN

ITEM	MODEL
49097	CE-IT-0045




PARTS BREAKDOWN

ITEM	MODEL
49097	CE-IT-0045



PARTS BREAKDOWN

ITEM	MODEL
49097	CE-IT-0045



PARTS BREAKDOWN

ITEM	MODEL
49097	CE-IT-0045

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AS249	Top Bin for 49097	1	AS260	Water Inlet Knob for 49097	12	AS271	Inox Flex Pipe for Spout DN10x800 for 49097	23
AS250	Front Door for 49097	2	AS261	Water Inlet Valve for 49097	13	AS272	Gas Tap 21/S with Fittings for 49097	24
AS251	Door Magnet for 49097	3	AS262	Nut FE/ZN D10 for 49097	14	AS273	Piezo Spark Plug for 49097	25
AS252	2" Stainless Steel Foot for 49097	4	AS263	Protection Pipe Exhaust for 49097	15	AS274	Burner Pasta Cooker S.90 for 49097	27
AS253	Top Drainer Grill for 49097	5	AS264	Water Inlet Valve Connection for 49097	16	AS275	Pilot Burner for 49097	28
AS254	Drain Cover for 49097	6	AS265	Water Tap Flange for 49097	17	AS276	Thermocouple CM60 for 49097	29
AS255	Stainless Steel Grid for 49097	7	AS266	Outlet Water Group for 49097	18	AS277	Knob for Gas Tap 21S with Red Logo for 49097	30
AS256	Exhaust Grate Extension H.130 L.450 for 49097	8	AS267	Gas Collector Bicone D10 for 49097	19	AS278	Plastic Cover for Gas Equipment for 49097	31
AS257	Cast Iron Exhaust Grate 450x70x40 for 49097	9	AS268	Spout for 49097	20	AS279	Piezoelectric Ignition for 49097	32
AS258	450 Gas Pasta Cooker Front Panel for 49097	10	AS269	Drain Hose for 49097	21	AS280	Ignition Cable CM.50 for 49097	33
AS259	Hinge for Door for 49097	11	AS270	Inox Flex Pipe Water Supply DN10x700 for 49097	22			