



PARTS BREAKDOWN

ITEM	MODEL
49100	CE-IT-0090PLUS




PARTS BREAKDOWN

ITEM	MODEL
49100	CE-IT-0090PLUS



PARTS BREAKDOWN

ITEM	MODEL
49100	CE-IT-0090PLUS



PARTS BREAKDOWN

ITEM	MODEL
49100	CE-IT-0090PLUS

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AS252	2" Stainless Steel Foot for 49100	1	AS297	Right Panel for 49100	13	AS269	Drain Hose for 49100	25
AS289	Top Bin for 49100	2	AS268	Spout for 49100	14	AS270	Inox Flex Pipe for Water Inlet DN10x700 for 49100	26
AS253	Top Drainer Grill for 49100	3	AS262	Nut FE/ZN D10 for 49100	15	AS285	Inox Flex Pipe for Water Inlet DN10x1200 for 49100	27
AS255	Stainless Steel Grid for 49100	4	AS267	Gas Collector Bicone D10 for 49100	16	AS286	Burner Pasta Cooker S.700 for 49100	28
AS290	Exhaust Grate Extension H.130 L.900 for 49100	5	AS260	Water Inlet Knob for 49100	17	AS279	Piezoelectric Ignition for 49100	29
AS257	Cast Iron Exhaust Grate 450x70x40 for 49100	6	AS261	Water Inlet Valve for 49100	18	AS278	Plastic Cover for Gas Equipment for 49100	30
AS296	900 Gas Pasta Cooker Plus Front Panel for 49100	7	AS265	Water Tap Flange for 49100	19	AS288	Knob for Gas Tap 22S with Red Logo for 49100	31
AS254	Drain Cover for 49100	8	AS294	T Junction for 49100	20	AS287	Gas Valve for 49100	32
AS281	Hinge for Door of Pasta Cooker Plus for 49100	9	AS264	Water Inlet Valve Connection for 49100	21	AS273	Piezo Spark Plug for 49100	33
AS282	Front Door for 49100	10	AS263	Protection Pipe Exhaust for 49100	22	AS280	Ignition Cable CM.50 for 49100	34
AS251	Door Magnet for 49100	11	AS293	Outlet Water Group DX for 49100	23	AS276	Thermocouple CM 60 for 49100	36
AS284	Left Panel for 49100	12	AS292	Outlet Water Group SX for 49100	24	AS275	Pilot Burner for 49100	37