


Parts Breakdown

Model CE-CN-0034MVHP 49398



Parts Breakdown


Model CE-CN-0034MVHP 49398

Item No.	Description	Position	Item No.	Description	Position
AX246	LAMP SOCKET BRACKET FOR 49398	Z41	AX258	NUT M5 FOR 49398	S15
AX247	PLASTIC NAIL FOR 49398	Z39	AX202	SCREW CT4*8TBHCFOR MICROWAVE 37962,49398	S07
AX248	SPACER FOR 49398	Z38	AX204	SCREW ST4*12PWBHCFOR MICROWAVE 37962,49398	S05
AX249	MOUNTING PLATE FOR 49398	Z34	AX205	SCREW ST4*10TBHCFOR MICROWAVE 37962,49398	S04
AX250	LAMP COVER FOR 49398	Z31	AX210	SCREW CT3*8BBHCFOR MICROWAVE 37962, 37963,49398	S01
AX182	GUARD OILFOR MICROWAVE 37962	Z29	AX259	FILTER FOR 49398	M06
AX251	WIND PREVENTOR FOR 49398	Z28	AX260	LAMP COVER FOR 49398	M05
AX252	VIBRATION ABSORBER FOR 49398	Z26	AX261	BOT LEVER FOR 49398	L08
AX189	CASE OUTFOR MICROWAVE 37962, 37963,49398	Z24	AX262	TOP LEVER FOR 49398	L07
AX190	FAN STIRRERFOR MICROWAVE 37962,49398	Z11	AX211	HARNESS MAINFOR MICROWAVE 37962, 37963,49398	L05
AX191	HOLDER H.V.CFOR MICROWAVE 37962, 37963,49398	Z01	AX212	MICROSWITCH MONITORFOR MICROWAVE 37962, 37963,49398	L04
AX197	MOTOR TRAYFOR MICROWAVE 37962, 37963,49398	T01	AX213	MICROSWITCH INTERLOCKFOR MICROWAVE 37962, 37963,49398	L03
AX253	VENT GRILLE FOR 49398	W11	AX215	BOARD LATCHFOR MICROWAVE 37962, 37963,49398	L01
AX254	UPPER WIND GUIDE FOR 49398	W08	AX263	UPPER HEAT INSULATOR FOR 49398	G09
AX255	PROTECTOR COVER FOR 49398	W07	AX254	THERMOSTAT 120°C/0°C FOR MICROWAVE 37963,49398	E44
AX256	SIDE HEAT INSULATOR FOR 49398	W05	AX216	THERMOSTAT 160°C/95°C FOR MICROWAVE 37962, 37963,49398	E35
AX229	GUIDE WINDFOR MICROWAVE 37962,49398	W04	AX217	POWER CORD ASSEMBLYFOR MICROWAVE 37962, 37963,49398	E16
AX193	MOTOR FANFOR MICROWAVE 37962, 37963,49398	W03	AX219	LAMPFOR MICROWAVE 37962, 37963,49398	E13
AX194	FANFOR MICROWAVE 37962, 37963,49398	W02	AX220	FUSEFOR MICROWAVE 37962, 37963,49398	E11
AX195	GUIDE FANFOR MICROWAVE 37962, 37963,49398	W01	AX221	FILTER NOISEFOR MICROWAVE 37962, 37963,49398	E10
AX257	SCREW CT4×6 PBHC FOR 49398	S23	AX222	HIGH VOLTAGE DIODEFOR MICROWAVE 37962, 37963,49398	E07
AX198	SPRING WASHERFOR MICROWAVE 37962,49398	S21	AX223	HIGH VOLTAGE CAPACITORFOR MICROWAVE 37962, 37963,49398	E06
AX199	SCREW 4*6FOR MICROWAVE 37962,49398	S18	AX224	HIGH VOLTAGE TRANSFORMERFOR MICROWAVE 37962, 37963,49398	E05
AX244	DOORFOR MICROWAVE 37962, 37963,49398	D00	AX225	MAGNETRONFOR MICROWAVE 37962, 37963,49398	E01

Parts Breakdown

Model CE-CN-0034MVHP 49398

Item No.	Description	Position	Item No.	Description	Position
AX249	CONTROL PANEL ASSEMBLYFOR MICROWAVE 37962, 37963,49398	C00	AX264	MOTOR BRACKET FOR 49398	A07
AX227	LEGFOR MICROWAVE 37962,49398	B02	AX265	BACK PLATE FOR 49398	A03
AX206	BASE PLANTFOR MICROWAVE 37962, 37963,49398	B01	AX207	ASSEMBLY CAVITYFOR MICROWAVE 37962, 37963,49398	A00
AX256	THERMOSTAT BRKT FOR MICROWAVE 37963,49398	A13	AX245	H.V.FUSE FOR 49398	E28
AX228	PRANT COVERFOR MICROWAVE 37962,49398	A09			



Parts Breakdown

Model CE-CN-0034MVHP 49398

Item No.	Description	Position	Item No.	Description	Position
AX266	SCREW ST4x30 PBHC FOR 49398	S34	AX241	LATCH SPRINGFOR MICROWAVE 37962, 37963,49398	D03
AX231	SCREW ST4x8PBHCFOR MICROWAVE 37962,49398	S03	AX242	LATCHFOR MICROWAVE 37962, 37963,49398	D02
AX232	HANDLEFOR MICROWAVE 37962, 37963	D14	AX243	DOOR FRAME ASSEMBLYFOR MICROWAVE 37962, 37963,49398	D01
AX257	METAL DOOR DECO FOR MICROWAVE 37962,49398	D09	AX244	DOORFOR MICROWAVE 37962, 37963,49398	D00
AX234	DOOR GASKETFOR MICROWAVE 37962, 37963,49398	D08	AX231	SCREW ST4x8PBHCFOR MICROWAVE 37962,49398	S03
AX235	DOOR PANELFOR MICROWAVE 37962, 37963,49398	D07	AX247	PCB ASSEMBLYFOR MICROWAVE 37962, 37963,49398	C18
AX233	DOOR DECORATIONFOR MICROWAVE 37962,49398	D06	AX238	MEMBRANE SWITCHFOR MICROWAVE 37962, 37963,49398	C17
AX237	DOOR INNER FILMFOR MICROWAVE 37962, 37963,49398	D05	AX239	CONTROL PANEL DECORATIONFOR MICROWAVE 37962,49398	C02
AX267	LATCH SHAFT FOR 49398	D39	AX248	CONTROL PANELFOR MICROWAVE 37962, 37963,49398	C01
			AX249	CONTROL PANEL ASSEMBLYFOR MICROWAVE 37962, 37963,49398	C00