
Parts Breakdown

Model FR-CN-0040-BK 50132

Model FR-CN-0040-WH 50133



Parts Breakdown

Model FR-CN-0040-BK 50132

Model FR-CN-0040-WH 50133

Item No.	Description	Position	Item No.	Description	Position
AT420	Back Grill for 50132, 50133	2	AA808	Left Upper Hinge for 50132, 50133	34
AA216	Drain Pipe for 50132, 50133	3	AH696	Gasket for 50132, 50133	35
26247	Caster without Brake for 50132, 50133	4	AX741	Right Glass Door for 50132, 50133	36
26246	Caster with Brake for 50132, 50133	5	AA857	Upper Right Hinge for 50132, 50133	37
AA874	Outer Drain Pan for 50132, 50133	6	AX742	Shelf for 50132, 50133	38
AE894	Right Track for Installation Board for 50132, 50133	7	AA809	K Strip for 50132, 50133	39
AT419	Caster Installation Board for 50132, 50133	8	26884	K Clip for 50132, 50133	40
AA304	Installation Board Block for 50132, 50133	9	AA722	Cabinet LED Light for 50132, 50133	41
AB974	Installation Board Handle for 50132, 50133	10	AU284	Drain Hose Block for 50132, 50133	42
AI385	Controller Waterproof Box for 50132, 50133	11	AX743	Air Pipe Protection Board for 50132, 50133	43
AX735	Front Grille for 50132, 50133	12	AG563	Power Supply for LED Light for 50132, 50133	44
26483	Digital Temperature Controller for 50132, 50133	13	AA969	Drain Hose for Inner Drain Pan for 50132, 50133	45
AA362	Light Switch for 50132, 50133	14	AI382	Temperature Sensor for 50132, 50133	46
43982	Power Switch for 50132, 50133	15	AU665	Temperature Sensor for Evaporator for 50132, 50133	47
AB977	Door Switch for 50132, 50133	16	AT250	Drain Nozzle Nut for 50132, 50133	48
AX736	Left Bottom Hinge for 50132, 50133	17	AX744	Drain Pan Heater for 50132, 50133	49
AA810	Bottom Hinge Axis for 50132, 50133	18	AX733	Fan Right Bracket for 50132, 50133	50
AA715	Axis Cover for 50132, 50133	19	AF036	Drain Nozzle for 50132, 50133	51
AE892	Left Track for Installation Board for 50132, 50133	20	AH713	Fan Blade Guide Ring for 50132, 50133	52
AX737	Condenser for 50132, 50133	21	AT423	Light Box Plate for 50132, 50133	53
AA854	Shelf Tag for 50132, 50133	22	AT424	Light Box Frame for 50132, 50133	54
AL996	Condenser Fan Motor Cover for 50132, 50133	23	AT425	LED Inside Light Box for 50132, 50133	55
AA764	Condenser Fan Blade for 50132, 50133	24	AH710	Power Switch LED Light for 50132, 50133	56
AX738	Condenser Fan Motor for 50132, 50133	25	AB992	Evaporator Cover for 50132, 50133	57

Parts Breakdown

Item No.	Description	Position	Item No.	Description	Position
	Compressor Accessories for 50132, 50133 (no Omcan part number yet)	26	AA764	Evaporator Fan Blade for 50132, 50133	58
AX739	Compressor for 50132, 50133	27	AX734	Fan Left Bracket for 50132, 50133	59
AA927	Power Cord for 50132, 50133	28	AX745	Evaporator Fan Motor for 50132, 50133	60
AB594	Filter for 50132, 50133	29	AA939	Drain Hose Heater for 50132, 50133	61
AB595	Filter Fixer for 50132, 50133	30	AX746	Evaporator Drain Pan for 50132, 50133	62
AE893	Compressor Installation Board for 50132, 50133	31	AJ157	Evaporator for 50132, 50133	63
AA695	Glass Door Handle for 50132, 50133	32	AX747	Defrost Heater for 50132, 50133	64
AX740	Left Glass Door for 50132, 50133	33	AX748	Bottom Right Hinge for 50132, 50133	65

Note: position 1 (cabinet) is not a spare part. Parts not listed here are not sold separately; contact Omcan Customer Service with the model and serial number from the rating plate. Position 26 (compressor accessories) has no Omcan part number yet; quote the position and the serial number when ordering.