



# PARTS BREAKDOWN

ITEM	MODEL
39522	JE-ES-0028-F



# PARTS BREAKDOWN


ITEM	MODEL
39522	JE-ES-0028-F




# PARTS BREAKDOWN

ITEM	MODEL
39522	JE-ES-0028-F

## STAINLESS STEEL SELF TAP OPTION




## AUTOMATIC SHOWER OPTION




# PARTS BREAKDOWN

ITEM	MODEL
39522	JE-ES-0028-F

## DISPENSER STAND OPTION



## SELF SERVICE STAND OPTION



# PARTS BREAKDOWN

ITEM	MODEL
39522	JE-ES-0028-F

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AP346	MB Grille Support for 39522	00017	40591	Female Thumbscrew M12 for 39522	00152	72533	Gear Feeder 3 Horiz for 39522	00226
AP347	MB Counter Adapter for 39522	00022	A0259	Magnet Cap for 39522	00167	64909	Stand Tray Rustless Screw M4x12 for 39522	00247
AP348	MB Grille for 39522	00025	72520	C Clip Din 471 E-34 for 39522	00168	A0261	Female Thumbscrew for 39522	00249
AP349	MB Door for 39522	00026	72521	Washer H D35-D09x3 Zinc for 39522	00171	64117	Tap for 39522	00251
AP350	MB Door for 39522	00027	AP160	Rustless Screw for 39522	00172	AP354	Rustless Screw for 39522	00268
AP351	MB Trolley Holder for 39522	00028	72644	Washer H Zinc Din-125 D10 for 39522	00173	72534	Plastic Lid M4 for 39522	00285
A0256	Cover Screen Bal for 39522	00029	72522	Rustless Washer Din-125 D08 Inox for 39522	00174	72535	Plastic Lid M6 for 39522	00286
A0257	Cover Screen Right Lid for 39522	00030	42173	Cotter H 8x7x70 for 39522	00175	40592	Female Thumbscrew M8 for 39522	00287
A0258	Cover Screen Left Lid for 39522	00031	72647	Rustless Cotter 8x7x50 for 39522	00177	72537	Male Thumbscrew M6 for 39522	00289
AP352	Down Tube (SOP) for 39522	00036	40590	Male Thumbscrew M8 for 39522	00178	72673	Reducer 14-160 R:1/28 for 39522	00294
72502	Screw H M8x30 Zinc for 39522	00048	64904	Screw H Zinc M8x20 for 39522	00179	64912	Reducer 14-160 R:1/20 for 39522	00295
72504	Cotter H 8x7x15 for 39522	00065	72649	Screw H M8x50 for 39522	00180	64913	Support Bracket Stand for 39522	00298
72506	Rustless Cotter Inox 8x7x70 for 39522	00067	72650	Rustless Screw M8x16 for 39522	00183	72674	Baseplate for 39522	00300
72623	Screw H M6x55 for 39522	00068	72651	Nut H Zinc M6 for 39522	00187	64914	Handle Stand for 39522	00317
72626	Screw H M6x10 for 39522	00077	64906	Nut H Zinc M8 for 39522	00188	64915	Lid Handle Stand for 39522	00319
72627	Bearing 6004 for 39522	00081	72526	Rustless Wingnut M4 Inox for 39522	00189	72541	Tray 150x120 for 39522	00322
AP159	Rustless Screw for 39522	00084	72653	Nut H Zinc M10 for 39522	00190	AP355	Plugging Cap for 39522	00340
72509	Rustless Screw M4x10 Inox for 39522	00086	72655	Ejector Rod M12 for 39522	00199	39695	Cover Screen for 39522	00344
72630	Screen Rod M8 for 39522	00088	39699	Blade Ejector for 39522	00201	AP356	Rustless Nut for 39522	00377
72631	Squeezer Male for 39522	00094	64908	Shaker Dispenser for 39522	00203	AP357	Rustless Nut for 39522	00385
72632	Squeezer Drum for 39522	00096	72657	DC Hose Fixing PG9 V-Tec 9GR for 39522	00211	64922	Stand Support Tray Stainless Steel Dispenser for 39522	00409
72514	Ventilation Grid for 39522	00108	64834	Plugging Cap Ø16mm Black for 39522	00212	64923	Plugging Cap PVC M4 Black for 39522	00416
72638	Sump Cover for 39522	00129	72532	Luggage-Rack 150x120 for 39522	00219	64924	Plugging Cap PVC M6 Black for 39522	00417
72639	Protect Juice Screen NA for 39522	00131	72659	Luggage-Rack 350x130 for 39522	00220	72564	Rustless Screw M6x12 Inox for 39522	00432
72640	Tray 350x130 for 39522	00136	72661	Gear Feeder 1 Reduct for 39522	00224	72565	Rustless Washer Din-6798 D06 Inox for 39522	00436
AP353	MB Dispenser Support for 39522	00147	72662	Gear Feeder 2 Cabez for 39522	00225	64925	Closing Device for 39522	00440

# PARTS BREAKDOWN

ITEM	MODEL
39522	JE-ES-0028-F

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
72691	Screw H Zinc M10x45 for 39522	00460	15403	Squeezer Male Big D80-D100 for 39522	00641	64952	DC Tee 6mm for 39522	00886
72693	C Clip Din-471 E16 for 39522	00489	15405	Squeezer Drum Big D80-D100 for 39522	00643	A0271	Feeder Base Basket for 39522	00900
14904	Blade Ejector Big D80-D100 for 39522	00490	64837	DC Shower Diffuser for 39522	00660	A0272	Head Feeder for 39522	00901
A0281	Blade Ejector for 39522	00492	64838	DC Shower Diffuser Cap for 39522	00661	A0273	Feeder Base Basket for 39522	00903
AP358	Rustless Screw for 39522	00500	64839	DC O-Ring for 39522	00662	AP369	Auto-F Motor Support for 39522	00904
72573	Rustless Screw M6x10 Inox for 39522	00503	64933	Stainless Steel Tube Guide M6x25 for 39522	00665	64119	Tap's Nut Valon for 39522	00905
AP359	Rustless Screw for 39522	00504	AP164	Rustless Nut for 39522	00668	A0274	Front Cover for 39522	00908
A0282	Squeezer Male for 39522	00507	AP367	Plugging Cap for 39522	00694	A0275	Gear Feeder for 39522	00911
A0283	Squeezer Drum for 39522	00508	AK899	Fixed Wheel for 39522	00708	A0276	Rustless Feeder Shaft for 39522	00913
A0263	Magnet for 39522	00509	AK900	Rotatory Brake Wheel for 39522	00709	72591	Washer H Zinc for 39522	00916
AP161	MB Down Tube Auto-F for 39522	00530	A0264	DC Valve for 39522	00750	A0277	Self-Tapping Insert for 39522	00918
72580	Rustless Screw M2.9x10 Inox for 39522	00541	44090	Rustless Screw Din-85 M4x14 Inox for 39522	00753	A0278	Turning Feeder Plate for 39522	00919
40602	Juicer Dispenser Cover for 39522	00544	40603	Juice Dispenser Base for 39522	00766	A0279	Feeder Tube for 39522	00920
64926	Rustless Filter for 39522	00545	64941	Rustless Screw M8x25 Inox for 39522	00767	A0285	Feeder Tube for 39522	00921
64927	Dispenser Support Inox for 39522	00549	64942	DC Adapter Male 6-1/4" for 39522	00771	AP174	Cover Screen for 39522	00923
72582	Rustless Screw M5x10 Inox for 39522	00555	64847	DC Adapter Male 6-1/4" for 39522	00772	AP175	Filter Body for 39522	00924
AP360	Close Tray for 39522	00571	A0265	DC Elbow for 39522	00775	AP176	Filter Band for 39522	00925
AP361	O-Ring for 39522	00572	64849	DC Elbow 6mm for 39522	00776	AP177	Filter Base for 39522	00926
AP362	Spring for 39522	00573	64851	DC Hose 6mm for 39522	00781	AP178	Roller for 39522	00927
AP363	Tap Pushbutton for 39522	00574	64943	DC E-Valve Shower Support for 39522	00784	79232	Separating Rod for 39522	00929
AP364	Down Tube for 39522	00575	A0266	Frontal Sheet for 39522	00798	79231	Separating Rod for 39522	00930
AP365	Peel Bucket Base for 39522	00579	A0267	Plugging Cap for 39522	00809	AP180	Auto-F Dice for 39522	00933
AP366	MB Ramp L250 for 39522	00630	A0284	Frontal Sheet for 39522	00813	AP181	Auto-F Motor Cover for 39522	00934
64118	Coupling Tap for 39522	00635	64946	Trolley 52L for 39522	00818	AK904	Rustless Screw for 39522	00958
64116	Tap's Washer for 39522	00637	64948	Back Cover Top NA E-Tron for 39522	00838	AP370	Tap Bottle Support for 39522	29043
64115	Tap's Nut for 39522	00638	64868	Magnet 10-05 for 39522	00859	AP371	Tap Bottle Support for 39522	29044
64932	Tap Nut Valon for 39522	00639	64875	Rustless Screw M2.9x13 Inox for 39522	00882	64953	Juice Dispenser Kit for 39522	70005

# PARTS BREAKDOWN

ITEM	MODEL
39522	JE-ES-0028-F

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AP372	Juice Tray Kit for 39522	70012	A0280	Feeder Support Kit for 39522	70042	AP379	Rustless Shaft Kit for 39522	70074
72616	Feeder Tube Kit MX for 39522	70013	AP375	Auto-F Motor Kit for 39522	70044	72654	Rubber Seal 30x40x06 for 39522	70075
AP373	Juice Dispenser MB Kit for 39522	70015	AP376	Auto-F Kit for 39522	70045	AP380	Seal Protection Kit for 39522	70076
64954	Sump Kit Bigbasic BK for 39522	70023	AP377	Reducer Shaft Kit for 39522	70071	AP381	Bearing Kit for 39522	70077
72738	Sump Kit BK for 39522	70024	AP378	Gear Kit for 39522	70072			
AP187	Juice Filter Auto-F Kit for 39522	70040	AK896	Upper Rustless Shaft 1 Piece for 39522	70073			