


Parts Breakdown

Model **DI-CN-0005** 39482



Parts Breakdown

Model DI-CN-0005 39482

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
73902	Tank Cover for 39482	1-A	AK781	Button of Overheat Protector for 39482	16	73936	Cleaner Shaft for 39482	33
AP808	Knob of Tank Lid for 39482	1-B	73920	Button Stop of Protector for 39482	17	73937	Tap Handle for 39482	34
76453	Paddle for 39482	2	AK783	Tank Hinge for 39482	18	73938	Screw of Faucet for 39482	35
AL383	Lid of Stirring Rod for 39482	3-A	73922	Upper Exterior for 39482	19	73939	Pin Spring for 39482	36
AK768	Stirring Rod for 39482	3-B	73923	Lower Exterior for 39482	20	73940	Pin for 39482	37
76456	PC Tank for 39482	4	AK786	Power Switch for 39482	21	73941	Lid of Water Bin for 39482	38
73908	Gasket of PC Tank for 39482	5	73925	Thermostat for 39482	22	73942	Water Bin for 39482	39
76458	Stainless Steel Boiler (Upper Part) for 39482	6	73926	Foot for 39482	23	73943	Drainage Plug for 39482	40
73910	Gasket for 39482	7	AK789	Ventilation Grill for 39482	24	73944	Lid of Water Tray for 39482	41
AK773	Overheat Protector for 39482	8	73928	Washer of Faucet (Interior) for 39482	25	27993	Float Indicator for 39482	42
AK774	Heater Element for 39482	9	73929	Nut of Faucet (Interior) for 39482	26	73946	Water Tray for 39482	43
73913	Boiler Gasket for 39482	10	76479	Gasket of Faucet for 39482	27	AK809	Forefoot for 39482	44
AK776	Electrical Stainless Steel Boiler (Lower Part) for 39482	11	73931	Nut of Faucet Exterior for 39482	28	AK810	Fan for 39482	45
73915	Supporter for 39482	12	73932	Gasket of Faucet Screw for 39482	29	73947	Supporter Off Fan for 39482	46
AK778	Motor for 39482	13	AK795	Gasket Inside the Faucet for 39482	30	AP810	Alarm Controller & Indicator Light for 39482	47
AK779	Back Cover for 39482	14	73934	Moving Pin for 39482	31	AP811	Float Switch for 39482	48
73918	Cover of Overheat Protector for 39482	15	73935	Faucet Spring for 39482	32			