


Parts Breakdown

Model MS-IT-0350-M 13639


Base



Parts Breakdown

Model MS-IT-0350-M 13639


Flywheel



Parts Breakdown

Model MS-IT-0350-M 13639


Blade Assembly



Parts Breakdown

Model MS-IT-0350-M 13639


Sharpening Assembly



Parts Breakdown

Model MS-IT-0350-M 13639


Cart




Parts Breakdown

Model MS-IT-0350-M 13639

Meat Tray Assembly




Sold Complete



Parts Breakdown

Model MS-IT-0350-M 13639

Advancement Cart




Parts Breakdown

Model **MS-IT-0350-M** 13639

Support Stand

Sold Complete



Parts Breakdown

Model MS-IT-0350-M 13639

Base

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33278	Screw TE for 13639	1	33285	Tray for 13639	8	33292	Thumb Screw for 13639	15
33279	Washer for 13639	2	33286	Blade Assembly Casing for 13639	9	33293	Screw for 13639	16
33280	Washer for 13639	3	33287	Pin for 13639	10	33296	Tray for 13639	19
33281	Square Bar Support for Plate for 13639	4	33288	Pin for 13639	11	33297	Housing for 13639	20
33282	Plate Stop for 13639	5	33289	Chain Guard for 13639	12	33298	Foot for 13639	21
33283	Washer for 13639	6	33290	Screw for 13639	13	33299	Nut for 13639	22
32692	Thumb Screw 5 MA for 13639	7	33291	Screw for 13639	14	33300	Washer for 13639	23

Flywheel

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33301	Gear Pivot for 13639	1	33319	Axial Bearing for 13639	19	33337	Oiler for 13639	37
33302	Gear for 13639	2	33320	Gear for 13639	20	33338	Oiler for 13639	38
33303	Rod / Counter for 13639	3	33321	Tapered Pin for 13639	21	33339	Bushing for 13639	39
33304	Set Screw for 13639	4	33322	Gear for 13639	22	33340	Gear Shaft for 13639	40
33305	Screw for 13639	5	33323	Tapered Pin for 13639	23	33341	Axial Bearing for 13639	41
33306	Washer for 13639	6	33324	Axial Bearing for 13639	24	33342	Axial Bearing for 13639	42
33307	Joint for 13639	7	33325	Axial Bearing for 13639	25	33343	Axial Bearing for 13639	43
33308	Screw for 13639	8	33326	Axial Bearing for 13639	26	33344	Set Screw for 13639	44
33309	Nut for 13639	9	33327	Screw Chrome for 13639	27	33345	Gear for 13639	45
33310	Pin for 13639	10	33328	Meat Grip Handle for 13639	28	33346	Cap for 13639	46
33311	Nut for 13639	11	33329	Pin for 13639	29	33347	Screw for 13639	47
33312	Joint for 13639	12	33330	Nut for 13639	30	33348	Pin for 13639	48
33313	Washer for 13639	13	33331	Tapered Pin for 13639	31	33349	Washer for 13639	49
33314	Washer for 13639	14	33332	Screw Chrome for 13639	32	33350	Bearing for 13639	50
33315	Carriage Slide Bar for 13639	15	33333	Fly Wheel for 13639	33	33351	Spacer for 13639	51
33316	Axial Bearing for 13639	16	33334	Set Screw for 13639	34	33352	Bearing for 13639	52
33317	Axial Bearing for 13639	17	33350	Bearing for 13639	35			
33318	Axial Bearing for 13639	18	33336	Bushing for 13639	36			

Parts Breakdown

Model MS-IT-0350-M 13639

Blade Assembly

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33353	Screw Chrome for 13639	1	33368	Chain Link for 13639	16	33383	Hinge for 13639	31
33354	Blade Washer for 13639	2	33369	Chain Link for 13639	17	33384	Meat Deflector for 13639	32
24041	Blade for 13639	3	33370	Chain Link for 13639	18	33385	Set Screw for 13639	33
33356	Screw TC 5x10 for 13639	4	33371	Thumb Screw for 13639	19	33386	Screw for 13639	34
33357	Bladering Guard for 13639	5	33372	Blade Guard for 13639	20	33387	Screw for 13639	35
33358	Screw for 13639	6	33373	Bracket for 13639	21	33388	Set Screw for 13639	36
33359	Washer for 13639	7	33374	Washer for 13639	22	33389	Bearing for 13639	37
33360	Spacer for 13639	8	33375	Screw for 13639	23	33390	Bearing Sleeve for 13639	38
33361	Set Screw for 13639	9	33376	Bracket for 13639	24	33391	Bearing for 13639	39
33362	Thumb Screw for 13639	10	33377	Screw for 13639	25	33392	Pin for 13639	40
33363	Set Screw for 13639	11	33378	Washer for 13639	26	33393	Washer for 13639	41
33364	Bearing and Shaft for 13639	12	33379	Screw for 13639	27	33394	Nut for 13639	42
33365	Gear Pig Z 15 for 13639	13	33380	Screw for 13639	28	33395	Nut for 13639	43
33366	Tapered Pin for 13639	14	33381	Washer for 13639	29	33396	Blade Shaft Cap for 13639	44
33367	Chain for 13639	15	33382	Screw for 13639	30	39117	Support Pin for 13639	45

Sharpening Assembly

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33537	Pin for 13639	1	33549	Sharpener Push Button for 13639	13	33561	Push Button Screw for 13639	25
33538	Knob for 13639	2	33550	Ball Bearing for 13639	14	33550	Ball Bearing for 13639	26
33539	Shaft for Sharpener for 13639	3	33547	Nut for 13639	15	33563	Spring for 13639	27
33540	Pin for 13639	4	33546	Washer for 13639	16	33564	Washer for 13639	28
33541	Nut for 13639	5	33545	45x13x6 Sharpening Stone for 13639	17	33565	Set Screw for 13639	29
33542	Pin for 13639	6	33554	Sharpener Pin for 13639	18	33566	Screw for 13639	30
33543	Nut for 13639	7	33555	Spring for 13639	19	33567	Washer for 13639	31
33544	Sharpener Pin for 13639	8	33546	Washer for 13639	20	33568	Sharpener Body for 13639	32
33553	Finishing Stone for 13639	9	33557	Screw for 13639	21	33569	Screw for 13639	33
33546	Washer for 13639	10	33558	Sharpener Cover for 13639	22	33570	Washer for 13639	34
33547	Nut for 13639	11	33559	Sharpener Cover Knob for 13639	23			
33548	Push Button Screw for 13639	12	33560	Sharpener Push Button for 13639	24			

Parts Breakdown

Model MS-IT-0350-M 13639

Cart

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33397	Rod for 13639	1	33422	Screw for 13639	26	33447	Rod for 13639	51
33398	Sharpener Support Bracket for 13639	2	33423	Washer for 13639	27	33448	Knob for 13639	52
33399	Set Screw for 13639	3	33424	Screw for 13639	28	33449	Set Screw for 13639	53
33400	Washer for 13639	4	33425	Washer for 13639	29	33450	Pin for 13639	54
33401	Screw for 13639	5	33426	Wire Bracket for 13639	30	33451	Slide for 13639	55
33402	Washer for 13639	6	33427	Cable for 13639	31	33452	Washer for 13639	56
33403	Bearing for 13639	7	33428	Wick for 13639	32	33453	Screw for 13639	57
33404	Carriage Rail for 13639	8	33429	Plate Base for 13639	33	33454	Set Screw for 13639	58
33405	Pin for 13639	9	33430	Screw for 13639	34	33455	Set Screw for 13639	59
33406	Foot for 13639	10	33431	Screw for 13639	35	33456	Set Screw for 13639	60
33407	Pin for 13639	11	33432	Wire Bracket for 13639	36	33457	Tapered Pin for 13639	61
33408	Washer for 13639	12	33433	Set Screw for 13639	37	33458	Screw for 13639	62
33409	Nut for 13639	13	33434	Washer for 13639	38	33459	Washer for 13639	63
33410	Set Screw for 13639	14	33435	Screw for 13639	39	33460	Washer for 13639	64
33411	Set Screw for 13639	15	33436	Bushing for 13639	40	33461	Bearing for 13639	65
33412	Flat Bracket for 13639	16	33437	Set Screw for 13639	41	33462	Pin for 13639	66
33413	Screw for 13639	17	33438	Bottom Plate Cover for 13639	42	33463	Pin for 13639	67
33414	Slide Bar Cover for 13639	18	33439	Screw for 13639	43	33464	Mount for 13639	68
33415	Screw for 13639	19	33440	Comb Block for 13639	44	33465	Plate for 13639	69
33416	Screw for 13639	20	33441	Support Mount for 13639	45	33466	Screw for 13639	70
33417	Carriage Slide Bar for 13639	21	33442	Spring for 13639	46	33467	Plate for 13639	71
33418	Bushing for 13639	22	33443	Screw for 13639	47	33468	Washer for 13639	73
33419	Carriage Support for 13639	23	33444	Bushing for 13639	48	33469	Washer for 13639	74
33420	Set Screw for 13639	24	33445	Bushing for 13639	49			
33421	Joint for 13639	25	33446	Set Screw for 13639	50			

Meat Tray Assembly

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33524	Complete Arm Assembly for 13639	1 - 38	33529	Set Screw for 13639	43	33534	Steel Pin for 13639	48
33525	Column for 13639	39	33530	Spacer for 13639	44	33535	Bottom Plate for 13639	49
33526	Column for 13639	40	33531	Top Plate for 13639	45	33536	Screw for 13639	50
33527	Set Screw for 13639	41	33532	Set Screw for 13639	46			
33528	Tightening Knob for 13639	42	33533	Set Screw for 13639	47			

Parts Breakdown

Model MS-IT-0350-M 13639

Advancement Cart

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
33470	Index Knob for 13639	1	33488	Nut for 13639	19	33506	Set Screw for 13639	37
33471	Indicator Numbers for 13639	2	33489	Nut for 13639	20	33507	Wheel Plate for 13639	38
33472	Set Screw for 13639	3	33490	Washer for 13639	21	33508	Set Screw for 13639	39
33473	Screw for 13639	4	33491	Wavy Washer for 13639	22	33509	Fly Wheel Assembly for 13639	40
33474	Screw for 13639	5	33492	Washer for 13639	23	33510	Handle for 13639	41
33475	Screw for 13639	6	33493	Feed Screw Shaft for 13639	24	33511	Threaded Pin for 13639	42
33476	Cam for 13639	7	33494	Bushing for 13639	25	33512	Socket Head Screw for 13639	43
33477	Spring for 13639	8	33495	Feed Screw Bushing for 13639	26	33513	Screw for 13639	44
33478	Pin for 13639	9	33496	Screw for 13639	27	33514	Nut for 13639	45
33479	Gear for 13639	10	33497	Washer for 13639	28	33515	Washer for 13639	46
33480	Tapered Pin for 13639	11	33498	Spacer for 13639	29	33516	Small Skip Latch for 13639	47
33481	Screw for 13639	12	33499	Pin for 13639	30	33517	Screw for 13639	48
33482	Washer for 13639	13	33500	Spring for 13639	31	33518	Screw for 13639	49
33483	Index Mount for 13639	14	33501	Pin for 13639	32	33519	Washer for 13639	50
33484	Rivet for 13639	15	33502	Large Skip Latch for 13639	33	33520	Spring and Latch for 13639	51
33485	Cam Pin for 13639	16	33503	Set Screw for 13639	34	33521	Spring for 13639	52
33486	Set Screw for 13639	17	33504	Gear for 13639	35	33522	Washer for 13639	53
33487	Bearing PVC for 13639	18	33505	Spring for 13639	36	33523	Screw for 13639	54

Support Stand

Item No.	Description	Position
33571	Pedestal Base for 13639	1 - 4