


# Parts Breakdown

Item 10883



# Parts Breakdown

---

## Item 10883

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
42344	Cover for 10883	1	42352	Washer for 10883	10	27341	Handle for 10883	17
42345	Gear Bracket - Driving Shaft for 10883	2	63999	Stainless Steel Sleeve (Short) for 10883	11	42359	Driven Shaft for 10883	18
42346	Gear Bracket Screws for 10883	3	42354	Upper Nylon Plate for 10883	11A	42360	Driving Shaft for 10883	19
18942	Gear for 10883	4	42355	Lower Nylon Plate for 10883	12	42361	Meat Combs for 10883	20
42347	Gear Bracket for 10883	5	42356	Stainless Steel Plate 2 for 10883	13	42362	Bolt of Base for 10883	21
42348	Stainless Steel Sleeve (Long) for 10883	6, 7	42357	Housing Bolt for 10883	14	42363	Nylon Base for 10883	22
42349	Stainless Steel Spacer for 10883	8	42358	Housing for 10883	15	42364	Nylon Bushing for 10883	23
42351	Knife for 10883	9	27340	Plastic Head Bolt for 10883	16	42365	Nylon Bushing for 10883	24