



Parts Breakdown

Item 11060



Parts Breakdown

Item 11060



Parts Breakdown

Item 11060

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AJ092	Base for 11060	1	AJ110	Bumper for Handle for 11060	23-5	AH835	Allen Cap Screw 3/4" for 11060	45
AJ093	Column for 11060	2	AH824	Pin for Lock Ring for 11060	24	AJ118	Allen Cap Screw 1/4" - 1" for 11060	46-5
45658	Exterior Shaft for 11060	3	AJ111	Bushing 1/2" for 11060	25-5	AH837	Plain Washer 1/4" for 11060	47
AJ094	Inside Shaft for 11060	4-5	44868	Bushing 3/4" for 11060	26	AH838	Internal Washer 3/4" for 11060	48
AJ095	Link Arm for 11060	5-5	AH825	Bushing 1/4" for 11060	27	AH839	Internal Washer 1/2" for 11060	49
AJ096	Lock Ring for 11060	6	AJ112	Allen Set Screw 1/4" - 20x1 1/2" for 11060	28	AJ119	Internal Washer 1/4" for 11060	50
AJ097	Block for 11060	7	AH826	Allen Set Screw 1" for 11060	29	AH840	Internal Washer 3/16" for 11060	51
AJ098	Plastic Guide for 11060	8	AC924	Complete Set of Blade for 11060	30	AH841	Lock Washer 1/4" for 11060	52
44869	Down Holder for Needler for 11060	9	AC925	Individual Blade for 11060	31	AJ120	Stainless Steel Rod 3/8" x 5 3/4" for 11060	56-5
AJ099	Guide with Bushing for Inside Shaft for 11060	10-5	AH827	Blades Spacer for 11060	32	AJ121	Allen Cap Screw 10-24 x 1/2" for 11060	57-5
AJ100	Eye Bolt for Spring for 11060	11	AH828	Threaded Rod for 11060	33	16278	C-Clip Shaft Holder for 11060	58-5
AJ101	Support for Handle for 11060	12-5	AJ113	Elastic Stop Nut for 11060	34	AJ122	Stainless Steel Hex Head Screw 10-32 x 3/8" for 11060	59-5
AJ102	Handle for 11060	13-5	AH829	Nut 3/4" for 11060	35	AH843	Stainless Steel Plain Washer 3/16" for 11060	60-5
16263	Square Bar for 11060	14	AJ114	Nut 1/2" for 11060	36	AJ123	Top Rubber Bumper for 11060	61-5
AJ103	Flat Bar for 11060	15	AH830	Nut 1/4" for 11060	37	AJ124	Bottom Rubber Washer for 11060	62-5
AJ104	Top Plate for 11060	16-5	AH831	Nut 3/16" for 11060	38	AH844	Stainless Steel Lock Washer 1/4" for 11060	63-5
AH823	Knurled Nut for 11060	17	AJ115	Stainless Steel Rod 3/8" x 7 for 11060	39	AJ125	Bracket for Hood for 11060	64-5
AJ105	Connecting Rod for 11060	18-5	AJ116	Bolt 1/4" x 2" for 11060	40	AJ126	Nut 3/8" for 11060	65-5
AJ106	Extension Bar for 11060	19	AH832	Bolt 1/4" x 1 1/2" for 11060	41	AJ127	Lock Washer 3/8" for 11060	66-5
AJ107	Sanitary Round Bar for 11060	20	AH833	Bolt 3/16" x 1 1/4" for 11060	42	AJ128	Bolt 3/8" - 16x2 1/2" for 11060	67-5
AJ108	Hood for 11060	21-5	AJ117	Metal Screw 1 1/2" - 14 for 11060	43			
AJ109	Spring for 11060	22	AH834	Screw for Hood for 11060	44-5			