



Parts Breakdown

Model MX-CN-0030-T 17836

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
24951	Dough Hook for 17836	1	24989	Gear for 17836	38-2	25026	Gear for 17836	71
24952	Beater for 17836	2	24990	Roller for 17836	38-3	25027	Gasket for 17836	72
24953	Wire Whip for 17836	3	24880	Spring for 17836	38-4	25028	Plug 1 for 17836	73
24954	Safety Guard for 17836	4	24992	Gear for 17836	39	25029	Nut for 17836	74
24955	Bowl for 17836	5	24901	Bushing for 17836	40	25030	Spring Washers for 17836	75
24956	Top Cover for 17836	6	24994	Sleeve for 17836	41	25084	Bearing for 17836	76
24960	Shifting Yoke for 17836	7-10	24995	Gear for 17836	42	25032	Shaft Worm Gear for 17836	77
24863	Cam-Gear Shifter for 17836	11	24996	Gasket for 17836	43	25008	Key for 17836	78
24864	Plate-Shifter Index for 17836	12	24997	Bearing for 17836	44	25034	Circlips for Shaft for 17836	79
24963	Handle-Shifter for 17836	13	24998	Bushing for 17836	45	25035	Circlips for Shaft for 17836	80
24964	Handle Set for 17836	14	24999	Oil Seal for 17836	46	25036	Plug 2 for 17836	81
24965	Turnset for 17836	15	25000	Body Housing for 17836	47	25037	Motor for 17836	82
24966	Speed Handle for 17836	16	25001	Bowl Hold Down Kit for 17836	48	25038	Rubber for 17836	83
24967	Plug for 17836	17	25002	Support for 17836	49	24922	Green Button Round for 17836	84
24968	Attachment Hub for 17836	18	25003	Spacer for 17836	50	25040	Red Stop Button without Timer CSA for 17836	85
24870	Tighten Handle for 17836	19	25004	Nut for 17836	51	25041	On/Off Switch/Button with Timer for 17836	85
24871	Ring for 17836	20	25005	Base for 17836	52	25042	Crank Lever for 17836	86
24971	Gear for 17836	21	25006	Bearing for 17836	53	25043	Handle-Shifter for 17836	87
24972	Hood Ring for 17836	22	25007	Transmission Shaft Support for 17836	54	25044	Connecting Rod for 17836	88
24973	Circlips for Shaft Q for 17836	23	25008	Key for 17836	55	24938	Spacer for 17836	89
24974	Planetary Gear for 17836	24	25009	Circlips for Shaft for 17836	56	25046	Spring for 17836	90
24975	Operating Shelf for 17836	25	25010	Gear for 17836	57	25047	Spacer for 17836	91
24905	Bearing 6205 for 17836	26	25011	Bushing for 17836	58	15559	Angle Iron for 17836	92
24977	Oil Seal for 17836	27	25012	Front Housing for 17836	59	25049	Rail Guide Plater for 17836	93
24978	Pin for 17836	28	25013	Worm Wheel-New for 17836	60	25050	Run Capacitor 60 UF - New for 17836	
24979	Working Shaft for 17836	29	25015	Mark for 17836	61	16323	Run Capacitor 40uf for 17836	
24980	Declutch Shift Shaft for 17836	30	25016	Case for 17836	62	25052	Start Capacitor 400 UF for 17836	
24939	Spacer for 17836	31	25017	Back Cover for 17836	63	25053	Contact-Relay for 17836	
24982	Main Shaft for 17836	32	25018	Internal Gear for 17836	64	25054	Power Cord for 17836	
24883	Nut for 17836	33	25019	Screw for 17836	65	25055	Reset-Overload Switch for 17836	
24984	Top Batter Valve Cap for 17836	34	25020	Seal Up Ring for 17836	66	24950	Rear Cover Screws for 17836	
24985	Plug Cover for 17836	35	25021	Gear Shaft for 17836	67	24947	Safety Guard-Bowl Switch for 17836	
25070	Bearing 6204 for 17836	36	25022	Gear for 17836	68	25152	Timer Knob for 17836	
24987	Spacer-Lower for 17836	37	25023	Bushing for 17836	69			
24988	Big Gear for 17836	38-1	25024	Brass Gear-New Style 28 Teeth for 17836	70			