


Parts Breakdown

Model DW-CN-0080-L 41872



Parts Breakdown

Model DW-CN-0080-L 41872

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AP755	Adjustable Feet for 41872	1	78041	Shelf Frame for 41872	17	69097	Heating Element Hanger 1 for 41872	33
AP765	Baseplate for 41872	2	AP769	LED for 41872	18	78043	Heating Element Frame 2 for 41872	34
78055	Drawer for 41872	3	70883	Door Hinge for 41872	19	78042	Right Panel for 41872	35
AP766	Power Driver for 41872	4	78033	Door Glass for 41872	20	79291	Wire Clip for 41872	36
70862	Thermostat T1/33 for 41872	5	78035	Handle for 41872	21	70688	Switch for 41872	37
70863	Thermostat T1M/33 for 41872	6	78034	Nail for Glass for 41872	22	AP771	Pilot Lamp for 41872	38
78062	Plug-Type Fixer for 41872	7	78069	Door Buckle 1 for 41872	23	70849	Temperature Controller for 41872	39
78063	Rear Panel for 41872	8	78070	Door Buckle 2 for 41872	24	AP772	Wire Clamp Fixing Seat for 41872	40
78061	Probe Pressing Plate for 41872	9	78027	Decorative Frame for 41872	25	61246	Wire Clip Holder for 41872	41
70877	Heating Element for 41872	10	78028	Top Glass for 41872	26	61245	Wire Clamp Cover for 41872	42
78067	Left Panel for 41872	11	AP770	Top Glass Support Plate for 41872	27	78053	Electric Box for 41872	43
78066	Front Panel for 41872	12	69092	B-Pillar for 41872	28	AP773	Electrical Cover for 41872	44
AP767	Bounding Box for 41872	13	78029	Top Glass Base B for 41872	29	60756	14mm Protecting Coil for 41872	45
60735	Water Receiver for 41872	14	69088	Side Glass for 41872	30	AK328	Power Cord for 41872	46
69094	LED Separator for 41872	15	78030	Top Glass Base A for 41872	31			
AP768	Grid Frame for 41872	16	69091	A-Pillar for 41872	32			