

Parts Breakdown

Model MX-IT-0030-R 47088

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AH116	Upper Casing ETL TA 30 VRN for 47088	02	AH059	Tank Protection ETL Vern. for 47088	50	AH113	Internal Wiring 220/60 UL TA for 47088	99
69217	Screw Poeliers M4x8 for 47088	04, 48, 72, 83, 138	AH076	Proximity Sensor TA for 47088	53, 51	AH007	Retaining Rings Din 471 D 25E for 47088	104, 212, 320
AH038	Chain 1/2x5/6" for 47088	06	AH096	Proximity Support for 47088	55	AH009	Feathers Din 6885 / A8x7x25 for 47088	106, 322, 355
AH031	Screw Din 916 M6x20 NE for 47088	08	AH115	Welded Frame ETL TA 30 Vern. for 47088	60	AH114	Transmission Shaft T1 30-40 for 47088	110
AG959	Pinion Z30 1/2x5/16" for 47088	10	62660	Washer F Wide Din 9021 D6x18 for 47088	61	AH039	Chain 3/8x7/32" for 47088	116
AH027	Nut ES. Din 934 M10 for 47088	12, 97, 132, 354	AH019	Screw TCEI Din 912 M6x10 for 47088	62	AH030	Grub Screw Din 916 M6x8 NE for 47088	118, 164, 304, 353
62645	Flat Washer Din 125 D10 for 47088	15, 135, 338, 358	AH066	Electric Box TGM2SIR MN for 47088	64	AH041	Pinion Z20 3/8x7/32" D25 for 47088	120
AH016	Washer F.Larga Din 9021 D10x30 for 47088	16	AH117	Rear Carter Y16 ETL TA 30 VRN for 47088	70B	AH044	Reducer NMRV 063 B14 1/30 FA 90 for 47088	128A, 130A
AH025	Screw TE Din 933 M10x35 T.F. for 47088	18, 362	AG952	Power Cable UL Thermal Protection for 47088	71A	62664	Screw TE Din 933 M10x20 T.F. for 47088	137
AH040	Pinion Z17 1/2x5/16" D20 for 47088	20	AH046	Thermal Protection T11-211 11A MN for 47088	73	AH061	Underdeck Protection for 47088	140
AH004	Grower Washer UNI 1751 D8 for 47088	21, 23, 226, 336	AH112	Power Cable Comp. 220/60 UL for 47088	74	AH065	ETL Thermoformed Protection for 47088	150
62663	X.Screw Din 933 M8x20 for 47088	22	AG991	Supp. Plate Prot. Term. MN for 47088	77B	69218	Screw Poeliers M5x8 for 47088	152
AH070	Washer F Wide Din 9021 D8x32 ZN for 47088	24	AH060	Plate. Controls Panel for 47088	78	AH063	Lid Frame for 47088	154
AH069	Screw without Head Din 916 M5x16 NE for 47088	26	AH011	Screw TC+Din 7985 M4x8 for 47088	79	AH013	Flathead CSK Screw Din 7991 M5x14 for 47088	156
AH050	Spacer for 47088	28	AG971	Face Plate. Controls Panel for 47088	80A	AH055	Lid Shaft for 47088	160
AH034	Ball Bearing 6204 2RS NTN for 47088	30, 34	AH012	Screw TSPEI Din 7991 M5x8 for 47088	82, 292	AG996	Plastic Washer 16x25x1 for 47088	161
AH037	Spiral Cast Iron Supp Y12 HRC 30 Lav. for 47088	32B	AH014	Washer F.Larga Din 9021 D4x12 for 47088	84, 273	AH006	Stop Rings Din 471 D15E for 47088	162
AH052	Dist.Int.Cusc.Supp.Spiral for 47088	33	AG949	Black Push Button N.O. for 47088	86	18960	Magnet for SO Anodized for 47088	166
AH049	Spiral Support Plate Y12 for 47088	36B	AG947	Stainless Steel Off Button Resin-Coated Y12 UL for 47088	86B	AG997	Cam TA for 47088	168
62644	Flat Washer Din 125 D8 for 47088	37, 334, 356	AG951	Unified Light UL 24 V for 47088	88	AG977	Washer for 47088	172
AH048	Spiral Y17 for 47088	40	AG950	White Push Button N.O. for 47088	90	AH026	Hex.Nut Din 934 M4 for 47088	177, 302
AH022	Screw TE Din 933 M8x25 T.F. for 47088	43, 234	AG948	Stainless Steel On Button with Light Y12 Resin UL for 47088	90B	AH000	Washer Flat Din 125 D.4 for 47088	179, 194
AH067	Feathers Din 6885 / A6x6x25 for 47088	46	AH120	Internal Panel ETL 30 TA for 47088	94	69215	Nut Din 934 M3 for 47088	182

Parts Breakdown

Model MX-IT-0030-R 47088

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AH017	Screw TCEI Din 912 M4x12 for 47088	184, 196, 271	AH086	Pin for 47088	258	AH104	Grub Screw Din 913 M4x35 CE for 47088	298
AG989	Corner Plate for 47088	190	AH124	Rubber Protection for 47088	260	AH122	Release Shaft TA 30 for 47088	300
AH054	Shaft for 47088	200	AH121	Rotating Disc 30 TA for 47088	262	AH123	Hinge Pin 30 TA for 47088	306
AH005	Grower Washer UNI 1751 D18 for 47088	201	AH118	Welded Head ETL TA 30 Vern. for 47088	270	AH075	Handle TA for 47088	310
AH033	Flat Washer Din 125 D18 Zinc for 47088	202	AH111	Gas Spring 084093 TA for 47088	272	AC008	Screw Din 916 M8x10 NE for 47088	321, 352
AH028	Nut ES. Din 934 M18 for 47088	204	AH105	Screw TE DIN 933 M6x30 T.F. for 47088	274	AH089	Transmission Shaft for 47088	324
AH051	Bowl 400x260 for 47088	210	62643	Flat Washer Din 125 D6 for 47088	275	AH103	Pin Inox Din 7 D10x50 for 47088	326
AG955	Bowl Holder for 47088	216	AH106	Hex.Nut Din 934 M6 for 47088	276	AH102	C-Clip.Retaining Din 471 D.20 Ext for 47088	327
AH110	Chain Ring Z85 3/8x7/32" for 47088	220	AH093	Hexagonal Screw for 47088	278	AH071	Head Holder for 47088	330
AH023	Screw TE Din 933 M8x35 T.F. for 47088	228	AH099	Washer Din 125 D12 for 47088	280	AH092	Transmission Joint TA for 47088	350
AG981	Shaft. Bowl Support for 47088	230	AH109	Self-Lock Nut ES Din982 M12 Low for 47088	282	AH074	Distance Transm. Joint 20-30 TA for 47088	351
AH032	Screw without Head Din 916 M8x16 NE for 47088	231	AH097	Supp. Cover Sensor M10 TA for 47088	283	AG958	Flange Support for 47088	360
AG945	Bearing 6205 2RS ORS for 47088	232, 328	AH094	Pin TA for 47088	284	AG969	3-Pole HRC Connector for 47088	372
AG998	Wheel ETL CMT1-3PBB for 47088	250A	AH077	Magnetic Sensor Head UL TA for 47088	288	AG970	8 Poles HRC Connector for 47088	374
AG999	ETL Wheel C/Brake CMT1-3PPB for 47088	250B	AH119	Protection Micro ETL TA 30 VRN for 47088	290	AH107	Screw without Head Din 916 M8x12 NE for 47088	380
AH087	Bowl Insert. TA for 47088	254	AH095	Release Lever. TA for 47088	294			
AH085	Fixed Disc TA for 47088	256	AH101	Retaining Rings Din 471 D 16E for 47088	296			