


Parts Breakdown

Model IC-CN-0050 47467



Parts Breakdown

Model IC-CN-0050 47467

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AL507	Cover for 47467	1	AL526	Spacer 8 for 47467	20	AL545	Small Drive Pulley for 47467	39
AL508	Magnet for 47467	2	AL527	Blade Support for 47467	21	AL546	Motor for 47467	40
AL509	Top Part for 47467	3	AL528	Outer Hexagon Bolt M5x14 for 47467	22	AL547	Outer Hexagon Bolt M10x25 for 47467	41
AL510	Screw ST4x10 for 47467	4	AL529	Outer Hexagon Bolt M5x32 for 47467	23	AL548	Spacer 10 for 47467	42
AL511	Front Panel for 47467	5	AL530	Shaved Ice Guide Bushing for 47467	24	AL549	Back and Side Shell for 47467	43
AL512	On/Off Switch for 47467	6	AL531	Adjuster Knob for 47467	25	AL550	Cable Clip for 47467	44
AL513	Pressing Ring for 47467	7	AL532	Support Rods for 47467	26	AL551	Power Cord for 47467	45
AL514	Guiding Ring for 47467	8	AL533	Hopper Base for 47467	27	AL552	Fuse Cover for 47467	46
AL515	Rotary Component for 47467	9	AL534	Water Pipe 13x10-300 for 47467	28	AL553	Handles for 47467	47
AL516	Hopper for 47467	10	AL535	Motor Support for 47467	29	AL554	Capacity for 47467	48
AL517	Inner Hexagonal Screw M8x20 for 47467	11	AL536	Front Shell for 47467	30	AL555	Wiring Harness for 47467	49
AL518	Nut M8 for 47467	12	AL537	Base for 47467	31	AL556	Chief Axis for 47467	50
AL519	Spacer 8 for 47467	13	AL538	Water Pipe 17x14-800 for 47467	32	AL557	Spring for 47467	51
AL520	Blade for 47467	14	AL539	Grid Cover for 47467	33	AL558	Bearing 35x14x11 for 47467	52
AL521	Screw M5x12 for 47467	15	AL540	Feet for 47467	34	AL559	Microswitch for 47467	53
AL522	Spacer 5 for 47467	16	AL541	Screw BT4x12 for 47467	35	AL560	PE Bag for 47467	54
AL523	Blade Adjuster for 47467	17	AL542	Belt for 47467	36	AL561	Left Foam for 47467	55
AL524	Dowel for 47467	18	AL543	Big Drive Pulley for 47467	37	AL562	Right Foam for 47467	56
AL525	Screw Arbor for 47467	19	AL544	Holding Screw M5x15 for 47467	38	AL563	Carton for 47467	57