


Parts Breakdown

Model VP-IT-0300 47718





Parts Breakdown

Model VP-IT-0300 47718

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AO021	Body for 47718	1	AO028	Seal Switch for 47718	11	AO038	Green Wiring for 47718	21
AO022	Base for 47718	2	AO029	Welding LED for 47718	13	AO039	Black Wiring for 47718	21
AO023	Cover for 47718	3	AO030	Green LED for 47718	14	AO040	Cable/Plug for 47718	22
AO024	Lower Vacuum Chamber for 47718	4	AO031	Vacuum Pump for 47718	15	AO041	Hinges with Screws for 47718	23
AO025	Upper Vacuum Chamber for 47718	5	AO032	Pump Base for 47718	16	AO042	Vacuum Socket for 47718	24
41618	Sealing Bar Complete for 47718	6	AO033	Solenoid Valve for 47718	17	AO043	Screw Rivet for 47718	25
72249	Top Bar for 47718	7	AO034	Electronic Board for 47718	18	AO044	Cover Screws for 47718	26
72246	Gasket for 47718	8	AO035	Filter Socket with Fuse for 47718	19	AO045	Base Feet for 47718	27
AO026	Vacuum Gauge for 47718	9	AO036	"N" Series Hose Set for 47718	20			
AO027	Start/Stop Switch for 47718	10	AO037	"NF" Series External Filter for 47718	20			