


Parts Breakdown

Model **CE-CN-0036-ET-1** 48528



Parts Breakdown

Model CE-CN-0036-ET-1 48528

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
AS888	Hotplate 2.6 kW for 48528	1	AQ198	Door Handle for 48528	17	66200	Leg for 48528	33
AS889	Heat Shield for 48528	2	AS902	Door Assembly for 48528	18	AS897	Power Cord Bushing for 48528	34
AS890	Hotplate Locking Bar for 48528	3	AJ578	Oven Door Hinge (Insert to the Door) for 48528	19	AS912	Terminal Block for 48528	35
AS891	Top Panel for 48528	4	AQ188	Kick Plate for 48528	20	AS913	Terminal Block Mounting Plate for 48528	36
AS892	Hotplate 2 kW for 48528	5	AQ187	Front Door Hinge Bracket Assembly for 48528	21	AS914	Cover for Internal Wiring for 48528	37
AS893	Heat Shield for 48528	6	AS903	Knob for 48528	22	AS915	Wiring Bushing for 48528	38
AS894	Hotplate Locking Bar for 48528	7	AS904	Oven Control Panel for 48528	23	AS916	Terminal Block for 48528	39
AS895	Front Panel for 48528	8	AS905	Thermostat for 48528	24	AD729	Power Cord Bracket for 48528	41
AS896	Front Heat Baffle for 48528	9	AS906	Infinite Switch for 48528	25	AS917	Side Panel for 48528	42
AS897	Power Cord Bushing for 48528	10	AD711	Working Indicator for 48528	26	AS918	Bottom Heating Element for 48528	43
AS898	Front Control Panel for 48528	11	AS907	Oven Bottom Plate for 48528	27	AS919	Top Heating Element for 48528	44
AS899	Knob for 48528	12	AS908	Cavity Right Side Panel for 48528	28	AS920	Heating Element Mounting Plate for 48528	45
AS900	Heat Separation Plate for 48528	13	AJ579	Oven Door Hinge Bracket for 48528	29	AS921	Heating Element Cover for 48528	46
AS901	Cavity Left Side Panel for 48528	14	AS909	Probe Bracket for 48528	30	AS922	Bottom Chimney Inside Liner for 48528	48
66215	Wiring Grid for 48528	15	AS910	Probe Outside Covering Bracket for 48528	31	AS923	Bottom Chimney Outside Liner for 48528	49
66216	Grid Rack for 48528	16	AS911	Probe Bracket for 48528	32	AS924	Back Plate Assembly for 48528	51