


Parts Breakdown

Model FP-IT-0003 10830



Parts Breakdown

Model FP-IT-0003 10830

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
38932	Foot for 10830	1	38961	Screw for 10830	30	38990	Set Screw for 10830	59
38933	Bottom for 10830	2	38962	Washer for 10830	31	38991	Screw for 10830	60
17854	Belt 510x10 for 10830	3	38963	Hinge Pin for 10830	32	38992	Washer for 10830	61
38935	Plate for 10830	4	38964	Hinge Support for 10830	33	38993	Capacitor & Bracket for 10830	62 - 63
38936	Screw for 10830	5	38965	Lever for 10830	34	38994	Screw for 10830	64
38937	Cable for 10830	6	38966	Thumb Knob for Lever for 10830	35	38995	Block Magnet for 10830	65
38938	Washer for 10830	7	38967	Washer for 10830	36	38996	Magnet for 10830	66
38939	Screw for 10830	8	15217	Lock Knob for 10830	37	38997	Shaft for 10830	67
38940	Washer for 10830	9	38969	Lever Handle for 10830	38	15223	Lid for 10830	68
38941	Screw for 10830	10	38970	Threaded Shaft for 10830	39	38999	Plug for 10830	69
38942	Screw for 10830	11	38971	Shaft Pin for 10830	40	39000	Screw for 10830	70
38943	Screw for 10830	12	38972	Clip for 10830	41	39001	Blade Support for 10830	71
38944	Nut for 10830	13	38973	Locking Pin for 10830	42	39002	Plug for 10830	72
38945	Washer for 10830	14	38974	Nut for 10830	43	39003	Blade for 10830	73
38946	Screw for 10830	15	38975	Driving Pot for 10830	44	39004	Spacer for 10830	74
38947	Motor Plate for 10830	16	38976	Screw for 10830	45	39005	Screws for 10830	75
38948	Cam Belt for 10830	17	38977	Micro Switch Pin for 10830	46	39006	Blade for 10830	76
38949	Nut for 10830	18	38978	Screw for 10830	47	39007	Pot for 10830	77
38950	Motor Pulley for 10830	19	15220	Microswitch for 10830	48	39008	Strain Relief for 10830	78
38951	Set Screw for 10830	20	38980	Set Screw for 10830	49	39009	Bracket for 10830	79
38952	Plug for 10830	21	38981	O-Ring Rubber for 10830	50	39010	Screw for 10830	80
38953	Screw for 10830	22	38982	Bearing and Shaft for 10830	51	39011	Screw for 10830	81
15213	Motor for 10830	23	38983	Pulley for 10830	52	39012	Pin for 10830	82
38955	Terminal Clamp for 10830	24	38984	O-Ring for 10830	53	39013	Complete Assembly for 10830	83
38956	On / Off Switch for 10830	25	38985	Bearing for 10830	54	39014	Nut for 10830	84
38957	Switch Assembly for 10830	26	38986	Spacer for 10830	55	39015	Micro Switch for 10830	85
14859	Power Cord for 10830	27	38987	Clip for 10830	56	39016	Terminal Clamp for 10830	86
38959	Housing for 10830	28	38988	Clip for 10830	57	39017	Screw for 10830	87
38960	Magnetic Microswitch for 10830	29	38989	Pulley for 10830	58	39018	Hallow Cable for 10830	88