


Parts Breakdown

Model MS-IT-0300-M 13634


Base



Parts Breakdown

Model MS-IT-0300-M 13634


Guide



Parts Breakdown

Model MS-IT-0300-M 13634


Blade Assembly



Parts Breakdown

Model MS-IT-0300-M 13634


Cart



Parts Breakdown

Model MS-IT-0300-M 13634



Thickness Adjustor



Parts Breakdown

Model MS-IT-0300-M 13634


Meat Tray Assembly



Parts Breakdown

Model MS-IT-0300-M 13634

Sharpening Assembly



Parts Breakdown

Model MS-IT-0300-M 13634

Base

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|---------------------------------|----------|----------|--------------------------------|----------|----------|--------------------------------|----------|
| 33047 | Screw Chrome for 13634 | 1 | 33058 | Chain Link for 13634 | 12 | 33069 | Washer 12 for 13634 | 23 |
| 33048 | Meat Grip Handle for 13634 | 2 | 33059 | Fly Chain for 13634 | 13 | 33070 | Nut 12 MA for 13634 | 24 |
| 33049 | Flywheel Handle Shaft for 13634 | 3 | 33060 | Set Screw 6x8 for 13634 | 14 | 33071 | Bronze Bushing 20x25 for 13634 | 25 |
| 33050 | Nut 12 MA for 13634 | 4 | 33061 | Gear Z45 Pig for 13634 | 15 | 33072 | Gear Pivot for 13634 | 26 |
| 33051 | Screw Chrome for 13634 | 5 | 33062 | Tapered Pin for 13634 | 16 | 33073 | Tapered Pin for 13634 | 27 |
| 33052 | Fly Wheel for 13634 | 6 | 33063 | Bronze Bushing 20x25 for 13634 | 17 | 33074 | Gear Z16 for 13634 | 28 |
| 33053 | Set Screw 6x8 for 13634 | 7 | 33064 | Gear Shaft for 13634 | 18 | 33075 | Gear Z32 for 13634 | 29 |
| 33054 | Tapered Pin for 13634 | 8 | 33065 | Oiler for 13634 | 19 | 33076 | Tapered Pin for 13634 | 30 |
| 33055 | Gear Shaft for 13634 | 9 | 33066 | Axial Bearing for 13634 | 20 | 33077 | Gear Z16 for 13634 | 31 |
| 33056 | Bronze Bushing 20x25 for 13634 | 10 | 33067 | Washer for 13634 | 21 | 33078 | Tapered Pin for 13634 | 32 |
| 33057 | Flywheel Casing for 13634 | 11 | 33068 | Bronze Bushing 20x25 for 13634 | 22 | 33079 | Spacer for 13634 | 33 |

Guide

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|--|----------|----------|------------------------------|----------|----------|------------------------------|----------|
| 33080 | Thumb Screw for 13634 | 1 | 33088 | Screw TE 8x30 for 13634 | 9 | 33095 | Washer 6 for 13634 | 17 |
| 33081 | Plate Stop for 13634 | 2 | 33089 | Screw TC 4x10 for 13634 | 10 | 33096 | Screw TE 8x20 Inox for 13634 | 18 |
| 33082 | Square Bar Support for Plate for 13634 | 3 | 37564 | Collection Plate for 13634 | 11 | 33097 | Washer 8 for 13634 | 19 |
| 33083 | Washer 8 for 13634 | 4 | 33090 | Slide Bar Cover for 13634 | 12 | 33098 | Carriage Rail for 13634 | 20 |
| 33084 | Slide Bar Support for 13634 | 5 | 33091 | Slide Bar Cap for 13634 | 13 | 33099 | Rail Support for 13634 | 21 |
| 33085 | Slide Bar Cap Screw for 13634 | 6 | 33092 | Carriage Slide Bar for 13634 | 14 | 33100 | Foot for 13634 | 22 |
| 33086 | Slide Bar Cap for 13634 | 7 | 33093 | Bracket for 13634 | 15 | | | |
| 33087 | Washer 8 for 13634 | 8 | 33094 | Screw TE 6x16 for 13634 | 16 | | | |

Rapid Approach

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|-------------------------|----------|----------|--------------------------|----------|----------|-------------------------------|----------|
| 33180 | Inox Rod 15 for 13634 | 1 | 33188 | Pin for 13634 | 9 | 33196 | Screw TE 6x16 for 13634 | 17 |
| 33181 | Spring for 13634 | 2 | 33189 | Lever Plate for 13634 | 10 | 33197 | Block Door on Plate for 13634 | 18 |
| 33182 | Screw TC 4x7 for 13634 | 3 | 33190 | Support Mount for 13634 | 11 | 33198 | Washer 6 for 13634 | 19 |
| 33183 | Steel Tab for 13634 | 4 | 33191 | Spring for 13634 | 12 | 33199 | Bearing 626 ZZ for 13634 | 20 |
| 33184 | Bushing 15 for 13634 | 5 | 33192 | Screw TE 6x16 for 13634 | 13 | 33200 | Bearing Stud for 13634 | 21 |
| 33185 | Set Screw 5x8 for 13634 | 6 | 33193 | Comb Block for 13634 | 14 | 33201 | Set Screw 6x8 for 13634 | 22 |
| 33186 | Slide for 13634 | 7 | 33194 | Screw TPSV 4x7 for 13634 | 15 | 33202 | Screw TE 6x16 for 13634 | 23 |
| 33187 | Handle for 13634 | 8 | 33195 | Pivot Rod for 13634 | 16 | | | |

Parts Breakdown

Model MS-IT-0300-M 13634

Blade Assembly

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|-----------------------------------|----------|----------|---------------------------------|----------|----------|-----------------------------|----------|
| 33101 | Screw Chrome for 13634 | 1 | 33115 | Washer 8 for 13634 | 15 | 33129 | Washer 10 for 13634 | 29 |
| 33102 | Blade Washer for 13634 | 2 | 33116 | Carriage Rail for 13634 | 16 | 33130 | Sharpener Pin for 13634 | 30 |
| 24040 | Blade for 13634 | 3 | 33117 | Carriage Rail Stop for 13634 | 17 | 33131 | Set Screw 6x8 for 13634 | 31 |
| 33104 | Screw TC 5x10 for 13634 | 4 | 33118 | Thumb Screw for 13634 | 18 | 33132 | Bearing 6202 ZZ for 13634 | 32 |
| 33105 | Blade Ring Guard for 13634 | 5 | 33119 | Blade Assembly Casing for 13634 | 19 | 33133 | Spacer Ring for 13634 | 33 |
| 33106 | Thumb Screw for 13634 | 6 | 33120 | Screw TC 3x5 for 13634 | 20 | 33134 | Bearing Sleeve for 13634 | 34 |
| 33107 | Blade Guard for 13634 | 7 | 33121 | Hinge for 13634 | 21 | 33135 | Bearing 6202 ZZ for 13634 | 35 |
| 33108 | Blade Guard Thumb Screw for 13634 | 8 | 33122 | Nut 4 MA for 13634 | 22 | 33136 | Rubber Pin 5x28 for 13634 | 36 |
| 33109 | Screw TC 6x12 for 13634 | 9 | 33123 | Screw TC 4x20 for 13634 | 23 | 33137 | Gear Pig Z15 for 13634 | 37 |
| 33110 | Washer 6 for 13634 | 10 | 33124 | Meat Deflector for 13634 | 24 | 33138 | Bearing and Shaft for 13634 | 38 |
| 33111 | Chain Guard for 13634 | 11 | 33125 | Screw TC 4x10 for 13634 | 25 | 33139 | Set Screw 6x8 for 13634 | 39 |
| 33112 | Pin for 13634 | 12 | 33126 | Washer 5 for 13634 | 26 | 33140 | Tray for 13634 | 40 |
| 33113 | Foot for 13634 | 13 | 33127 | Blade Shaft Cap for 13634 | 27 | 33141 | Screw TE 6x16 for 13634 | 41 |
| 33114 | Nut 8 MA for 13634 | 14 | 33128 | Nut 10 MA for 13634 | 28 | 33142 | Thumb Screw for 13634 | 42 |

Cart

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|---------------------------|----------|----------|-----------------------------|----------|----------|-------------------------------------|----------|
| 33143 | Joint Bolt for 13634 | 1 | 33156 | Screw TE 10x40 for 13634 | 14 | 33169 | Sharpener Support Bracket for 13634 | 27 |
| 33144 | Joint for 13634 | 2 | 33157 | Plate Base for 13634 | 15 | 33170 | Set Screw 6x8 for 13634 | 28 |
| 33145 | O-Ring for 13634 | 3 | 33158 | Screw TE 8x20 for 13634 | 16 | 33171 | Plate Support Bar for 13634 | 29 |
| 33146 | Nut 10 for 13634 | 4 | 33159 | Washer 8 for 13634 | 17 | 33172 | Slide Bar for 13634 | 30 |
| 33147 | Rod Lever for 13634 | 5 | 33160 | Set Screw 5x8 for 13634 | 18 | 33173 | Bottom Plate Cover for 13634 | 31 |
| 33148 | Nut 10 for 13634 | 6 | 33161 | Bushing 20x25 for 13634 | 19 | 33174 | Screw TPSV 3x7 for 13634 | 32 |
| 33149 | Support Mount for 13634 | 7 | 33162 | Carriage Support for 13634 | 20 | 33175 | Washer 8 for 13634 | 33 |
| 33150 | Pin 5x12 Inox for 13634 | 8 | 33163 | Set Screw 5x8 for 13634 | 21 | 33176 | Bearing 608 ZZ for 13634 | 34 |
| 33151 | Set Screw 6x40 for 13634 | 9 | 33164 | Bottom Plate for 13634 | 22 | 33177 | Pin for 13634 | 35 |
| 33152 | Washer 12 for 13634 | 10 | 33165 | Plate Support Bar for 13634 | 23 | 33178 | Screw TPSV 6x12 for 13634 | 36 |
| 33153 | Screw TPSV 8x16 for 13634 | 11 | 33166 | Screw TPSV 4x18 for 13634 | 24 | 33179 | Set Screw 6x8 for 13634 | 37 |
| 33154 | Washer for 13634 | 12 | 33167 | Screw TC 5x10 for 13634 | 25 | | | |
| 33155 | Joint for 13634 | 13 | 33168 | Screw TE 8x20 for 13634 | 26 | | | |



Parts Breakdown

Model MS-IT-0300-M 13634

Thickness Adjustor

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|-----------------------------|----------|----------|-----------------------------|----------|----------|--------------------------------------|----------|
| 33203 | Handle for 13634 | 1 | 33216 | Set Screw 6x6 for 13634 | 14 | 33229 | Screw TPSV 4x10 for 13634 | 27 |
| 33204 | Set Screw 5x8 for 13634 | 2 | 33217 | Screw TC 4x5 Inox for 13634 | 15 | 33231 | Feed Screw Shaft for 13634 | 29 |
| 33205 | Spring for 13634 | 3 | 33218 | Washer 4 for 13634 | 16 | 33232 | O-Ring for 13634 | 30 |
| 33206 | Adjustment Wheel for 13634 | 4 | 33219 | Small Spring for 13634 | 17 | 33233 | Washer 6 for 13634 | 31 |
| 33207 | Cam for 13634 | 5 | 33220 | Screw TE 6x16 for 13634 | 18 | 33234 | Nut with Non-Stick Coating for 13634 | 32 |
| 33208 | Indicator Numbers for 13634 | 6 | 33221 | Small Skip Latch for 13634 | 19 | 33235 | Nut for 13634 | 33 |
| 33209 | Copper Rivet for 13634 | 7 | 33222 | Big Skip Latch for 13634 | 20 | 33236 | Screw TC 4x16 for 13634 | 34 |
| 33210 | Screw TC 5x10 for 13634 | 8 | 33223 | Set Screw for 13634 | 21 | 33237 | Large Spring for 13634 | 35 |
| 33211 | Set Screw for 13634 | 9 | 33224 | Set Screw PVC 8 for 13634 | 22 | 33238 | Set Screw for 13634 | 36 |
| 33212 | Screw TC 4x10 for 13634 | 10 | 33225 | Skip Block for 13634 | 23 | 33239 | Washer 8 for 13634 | 37 |
| 33213 | Washer for 13634 | 11 | 33226 | Washer 6 for 13634 | 24 | 33240 | Nut 8 for 13634 | 38 |
| 33214 | Bracket for 13634 | 12 | 33227 | Screw TE 6x20 for 13634 | 25 | | | |
| 33215 | Gear for 13634 | 13 | 33228 | Bushing 12 for 13634 | 26 | | | |

Meat Tray Assembly

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|---------------------------------|----------|----------|---------------------------|----------|----------|----------------------|----------|
| 33241 | Complete Arm Assembly for 13634 | 1 - 35 | 33245 | Spacer for 13634 | 39 | 33249 | Plate Lock for 13634 | 43 |
| 33242 | Screw Chrome for 13634 | 36 | 33470 | Index Knob for 13634 | 40 | 33250 | Top Plate for 13634 | 44 |
| 33243 | Long Column for 13634 | 37 | 33247 | Set Screw 12 for 13634 | 41 | | | |
| 33244 | Short Column for 13634 | 38 | 33248 | Screw TPSV 4x10 for 13634 | 42 | | | |

Sharpening Assembly

| Item No. | Description | Position | Item No. | Description | Position | Item No. | Description | Position |
|----------|-------------------------------|----------|----------|------------------------------------|----------|----------|---------------------------------|----------|
| 33251 | Shaft for Sharpener for 13634 | 1 | 33261 | Push Button Screw for 13634 | 12 | 33268 | Washer 6 for 13634 | 20 |
| 33252 | Pin for 13634 | 2 | 31196 | Screw for 13634 | 12 | 33269 | Screw TPSV 6x12 for 13634 | 21 |
| 33253 | Pin for 13634 | 3 | 31197 | Sharpener Push Pin for 13634 | 13 | 33270 | Sharpener Cover for 13634 | 22 |
| 33254 | Nut 5 for 13634 | 4 | 33262 | Sharpener Push Button for 13634 | 13 | 33271 | Sharpener Cover Knob for 13634 | 23 |
| 33255 | Set Screw 6x8 for 13634 | 5 | 33263 | Ball Bearing for 13634 | 14 | 33272 | Sharpener Push Button for 13634 | 24 |
| 33256 | Screw TC 4x16 for 13634 | 6 | 33264 | Nut 6 for 13634 | 15 | 33273 | Spring for 13634 | 25 |
| 33257 | Washer 5 for 13634 | 7 | 33265 | Washer 6 for 13634 | 16 | 33274 | Washer for 13634 | 26 |
| 33258 | Sharpener Pin for 13634 | 8 | 33545 | 45x13x6 Sharpening Stone for 13634 | 17 | 33275 | Screw TC 3 for 13634 | 27 |
| 33553 | Finishing Stone for 13634 | 9 | 33266 | Sharpener Pin for 13634 | 18 | 33276 | Washer 3 for 13634 | 28 |
| 33259 | Washer 6 for 13634 | 10 | 31198 | Shaft for 13634 | 18 | 33277 | Sharpener Body for 13634 | 29 |
| 33260 | Nut 6 for 13634 | 11 | 33267 | Spring for 13634 | 19 | | | |