


# PARTS BREAKDOWN

ITEM	MODEL
50005	VP-NL-0063-M



# PARTS BREAKDOWN

ITEM	MODEL
50005	VP-NL-0063-M

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35590	Vacuum Chamber Complete for 50005	10	35252	Gas Valve for Gas Distribute Pot for 50005	210	35276	Spring Ring 12mm Din471 for 50005	510
35231	Branch Pipe HFE-1 Ready for 50005	20	35253	Closing Plug Silicone Holder for 50005	220	27827	Flat Washer M10 D9021 A2 for 50005	520
35232	O-Ring 32x3 for 50005	30	35254	Reducing Nipple 1/2"x3/8" for 50005	230	35636	Adj.Screw/Soc.Head M10x60 Din913 A2 for 50005	530
35233	Filter for 50005	40	35255	Distribution Block 4DVB/VP 3/8"-1/4"-4 for 50005	240	35637	Bush Hinge Pin SB-820 for 50005	535
35234	Adj.Screw/Soc.Head M8x30 Din916 A2 for 50005	50	35256	Air Pressure Hose Blue 10x8 for 50005	245	35279	Self Locking Hexagon Nut M10 Din985 VZ for 50005	540
27814	Hexagon Nut M8 Din934 A2 for 50005	60	35257	Insert Coupling Straight 1/4"x10 for 50005	250	27819	Square Hose Coupling 1/8"x6 Ext. for 50005	550
35236	Spring Ring M8 Din127 A2 for 50005	70	35258	Blind Plug 3/8" MS/VN for 50005	255	15751	Decompress Filter 1/2 for 50005	570
35597	Hex.Socket Head Cap Screw M5x35 Din912 A2 for 50005	80	15716	3-Way Valve for 50005	260	35282	T-Screw-in Hose Coupling 1/8"x6 Ext. for 50005	580
15722	Vacuum Valve without Decomp. Head 32mm for 50005	90	30015	Square Hose Coupling 1/4"x6 Ext. for 50005	270	35203	Plug Plastic 1/8" for 50005	810
15723	Decompress Head Vacuum Valve 32mm for 50005	100	35261	Brass Hose Coupling 1/4"x8 Ext. for 50005	350	35284	Extension Piece Oil Drain for 50005	820
35600	Support Gas Cylinder SB-820 for 50005	110	15775	Micro Switch MV3003L for 50005	370	35285	Valve 2/2 MA-222-003-P27-SAH 24 for 50005	830
35242	Packing Branch Pipe Mobiles for 50005	120	27823	Hexagon Nut M3 Din934 A2 for 50005	380	35205	Brass Double Nipple 1/8" for 50005	840
15754	Gas Cylinder (H-3000) for 50005	125	27822	Castle Washer M3 for 50005	390	35225	Silencer ID-CL 1/8 for 50005	850
35603	Gas Cylinder 084174 / 500N for 50005	130	30011	Slotted Cheese Head Screw M3x20 A2 Din84 for 50005	400	35647	Protection Suction Hole SB-820-LL for 50005	860
35604	Hexagon Screw M8x30 Din933 A2 for 50005	135	27781	Hexagon Flangenut M6 Din6923 A2 for 50005	420	35648	Insert Plate SB-820 KL for 50005	900
27814	Hexagon Nut M8 Din934 A2 for 50005	140	35627	Hex.Sock.Counter Head Screw M6x20 D7991 A2 for 50005	430	35649	Insert Plate SB-820 LL for 50005	910
35219	Flat Washer M8 D9021 A2 for 50005	150	35628	Hex.Sock.Counter Head Screw M6x16 D7991 A2 for 50005	450	35650	Insert Plate SB-820 KK for 50005	920
35247	Blind Stopper + O-Ring 1/4 MS/VN for 50005	170	27781	Hexagon Flangenut M6 Din6923 A2 for 50005	460	35651	Vacuum Cover SB-820 Complete for 50005	1010
35248	Hose Coupling 1/2"x10 Ext. for 50005	180	35272	Hex.Socket Head Cap Screw M5x8 Din912 A2 for 50005	470	35652	Sight Glass SB-820 (560x315x20) for 50005	1020
35249	Elbow Coupling 10x1/4" for 50005	190	35273	Hinge Pin for 50005	480	35105	Sil.Profile Lid Gasket 8mm 60°SH/25MTR for 50005	1030
35250	Gas Nozzle Universal for 50005	200	35274	Spring Collar for 50005	490	35292	Lid Locker Hook V951L7-1BP for 50005	1040
35251	Hexagon Nut M8x1 Low Din439B for 50005	205	35275	Safety Pin Hinge for 50005	500	35293	Slotted Cheese Head Screw M3x5 A2 Din84 for 50005	1050

# PARTS BREAKDOWN

ITEM	MODEL
50005	VP-NL-0063-M

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
27788	Adj.Screw/Soc.Head M6x25 Din916 A2 for 50005	1060	15818	Fuse 5x20 4A Slow for 50005	2075	35700	Pump Cord CM4-13 for 50005	2251
35295	Rod End Hinge Cover for 50005	1070	15817	Fuse 5x20 8A Slow for 50005	2076	35330	Valve Cord CC2-02 for 50005	2260
35658	Wire Bush M12 (Cover SB-820) for 50005	1075	15784	TMBR AB193-TAB40 2 4-4 0A for 50005	2080	35702	Cable Looping Seal Beam for 50005	2270
27808	Adjusting Fork for 50005	1080	15781	TMBR AB193-TAPM Mounting Base for 50005	2085	35331	Cable Channel 40x40 for 50005	2280
27809	Adjusting Fork Closing Pin for 50005	1090	35315	Double Clamp 2,5-2 for 50005	2090	35332	Cable Microswitch for 50005	2290
35661	Bearing Bush PAP-0606-P10 for 50005	1100	15771	Closed Contactor 24VAC for 50005	2110	35333	WM01 Feed Transformer Primary for 50005	2300
35662	Hexagon Screw M12x25 Din933 A2 for 50005	1110	35317	Earth Terminal PE 6-10 for 50005	2130	35706	WM02 Looping Mas Seal 1 2.5 for 50005	2310
35663	Flat Washer M12 Din9021 A2 for 50005	1115	35318	Wire Clamp 6-2/2 AN for 50005	2140	35334	WM05 Looping Transformer Primary for 50005	2330
35355	Cable Clip 1x10mm Din72571 for 50005	1120	35319	Rail JMV35SL 9-Hole 220mm for 50005	2150	35335	WM06 Mas Pump-Threading Clamp for 50005	2340
35665	Tube Alu 10x1mm L=680mm SB-820 for 50005	1130	35687	Wire Clamp 2.5-2/2 AN for 50005	2160	35336	WM11 Pump Cable Mas-Mbs 2.5 for 50005	2350
35666	Tube Alu 10x1mm L=370mm SB-820 for 50005	1140	35688	Clamp Connector 2.5/2 for 50005	2165	35710	WC01 Control-Cable Mas Seal 1,0 for 50005	2360
35667	Tube Alu 10x1mm L=420mm for 50005	1150	35320	Hex.Socket Head Cap Screw M4x8 Din912 A2 for 50005	2170	35711	WC03 Looping Clixon for 50005	2370
35298	Cable Gland M20x1,5 Brass for 50005	1160	34998	Flat Washer M4 D9021 A2 Carriage Ring M4 for 50005	2175	35337	WC04 Control Transformer Fuse-Clip for 50005	2380
35299	Handle GN-565-26-192-SW 800 for 50005	1200	35322	Earth Terminal M4 1x45-GR for 50005	2180	35338	WE02 Ground Cord Machine-PE 2,5 for 50005	2390
35300	Hexagon Screw M8x20 Din933 A2 for 50005	1210	35323	End Plate Wire Connector for 50005	2190	35714	Interconnection Double MAS100C09 for 50005	2400
35301	Castle Washer Red Copper M8 for 50005	1220	35324	Seal Cord C1-07 for 50005	2200	15935	Seal Bag 3000800-L L=620mm for 50005	3010
35672	Plate 495x230x5 for 50005	2000	35326	Control Cable CC1-01 for 50005	2210	15936	Seal Bag 3000800-K(KL) L=340mm for 50005	3020
15792	Combi-Trafo P200/460V-S24/32V for 50005	2020	35327	Network-Cord CM 1-11 for 50005	2220	15937	Seal Bag 3000800-K(KK) L=375mm for 50005	3025
35304	Earth Terminal PE 4-2/3 for 50005	2030	35696	Network-Cord CM1-03 for 50005	2221	35718	Pressure Beam SB-820-L for 50005	3030
35305	End Fent for 50005	2050	35328	Feed Main Switch CM2-04 for 50005	2230	35719	Pressure Beam SB-820-K(KL) for 50005	3035
35306	Fuse Clamp 2,5-2/ZSI for 50005	2060	35698	Feed Main Switch CM2-02 for 50005	2231	35720	Pressure Beam SB-820-K for 50005	3040
35307	Fuse Keram.5x20 2.5A Delay for 50005	2070	35329	Pump Cord CM4-09 for 50005	2250	35721	Silicon Holder SB-820-K for 50005	3045

# PARTS BREAKDOWN

ITEM	MODEL
50005	VP-NL-0063-M

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
35722	Silicon Holder SB-820-K-G for 50005	3046	62579	Sealbeam 8mm/1/540 for 50005	3200	35368	Spring Control Box for 50005	4020
35723	Silicon Holder SB-820-K (KL) for 50005	3050	15891	Seal Beam Single Seal L=550mm Complete for 50005	3210	35369	Swivel Castor Black ST.ST. 100mm for 50005	4030
35724	Silicon Holder SB-820-K(KL)-G Right for 50005	3051	27837	Hose (O2) Drago 6x13 for 50005	3290	35370	Fixed Castor STST. for 50005	4040
35725	Silicon Holder SB-820-K(KL)-G Left for 50005	3052	30016	Square Connect Piece 6mm for 50005	3300	35211	Hexagon Screw M8x16 Din933 A2 for 50005	4050
35726	Silicon Holder SB-820-L for 50005	3055	27836	Connecting Piece T-Piece 6mm for 50005	3310	35372	Castle Washer M8 for 50005	4060
35727	Silicon Holder SB-820-L-G for 50005	3056	30019	Hose Clip Klemfa 12.8x14.8mm for 50005	3320	27814	Hexagon Nut M8 Din934 A2 for 50005	4065
35728	Sealing Mechanism SB-820-L Top for 50005	3060	35352	Cable Clamp 1x12mm Din7257 for 50005	3330	35298	Cable Gland M20x1,5 Brass for 50005	4070
35729	Sealing Mechanism SB-820-LL Bottom for 50005	3065	35353	Self Tapping Screw Pias 3.5x9.5 for 50005	3340	35375	Nut M20x1.5 MS for 50005	4075
35730	Seal Mechanism SB-820-KL Top for 50005	3070	31554	Adj.Screw/Soc.Head M6x6 Din916 A2 for 50005	3430	35376	Cable Gland M20x1,5 Plastic for 50005	4080
35731	Seal Mechanism SB-820-KL Bot-tom for 50005	3075	15842	Silicone T-Profil 40 Shore One Meter for 50005	3490	35377	Lid Locker for 50005	4160
35732	Seal Mechanism SB-820-K Upper for 50005	3080	35447	Castle Washer M10 for 50005	3560	27822	Castle Washer M3 for 50005	4165
35733	AI Mechanism Under for 50005	3085	35755	Protect.Case Bolt Seal.Mechanism 10x1x50mm for 50005	3570	35293	Slotted Cheese Head Screw M3x5 A2 Din84 for 50005	4170
15889	Seal Beam Single Seal L=500mm Complete for 50005	3100	35756	Spring Cutting System TPS/Seal M. SB-820 for 50005	3580	30026	Slott.Rais.Counter.Head Screw M4x12 Din7985 A2 for 50005	4180
35346	Seal Beam DS/1/495 for 50005	3110	35372	Castle Washer M8 for 50005	3590	35381	Terminal Block 4-Pole for 50005	4200
62573	Sealbeam TS/1/495 for 50005	3120	35758	Hexagon Screw M8x60 Din933 A2 for 50005	3600	35382	Cover Connection Block 4-Pole for 50005	4210
62574	Sealbeam 8mm/1/495 for 50005	3130	27787	Hexagon Screw M6x16 DIN933 A2 for 50005	3650	35380	Slotted Cheese Head Screw M4x12 A2 Din84 for 50005	4220
15894	Seal Beam Single Seal L=800mm Complete for 50005	3140	35760	Spring Ring M6 Din127 A2 for 50005	3660	35782	Vac.Pump 063-122 230/400-3-50 E for 50005	5010
62575	Sealbeam DS/1/795 for 50005	3150	35507	Holing Block Silicon Holder HD-03 for 50005	3690	35388	Hose Clip ABA 32-44mm for 50005	5040
62576	Sealbeam TS/1/795 for 50005	3160	35364	O-Ring 27x2.5 for 50005	3700	15833	PVC Suction Hose HNA-32x42mm for 50005	5050
62577	Sealbeam 8mm/1/795 for 50005	3170	35365	Mounting Screw Holing Block HD-03 for 50005	3740	35390	Pipe Nipple Half 1/2 1" for 50005	5060
35742	Seal Beam DS/1/540 for 50005	3180	35764	Spacer Sil.Holder Gas 68mm for 50005	3750	35391	Adj.Screw/Soc.Head M8x25 Din916 A2 for 50005	5070
62578	Sealbeam TS/1/540 for 50005	3190	35765	Bottom Section SB-820 for 50005	4010	35219	Flat Washer M8 D9021 A2 for 50005	5080

# PARTS BREAKDOWN

ITEM	MODEL
50005	VP-NL-0063-M

Item No.	Description	Position	Item No.	Description	Position	Item No.	Description	Position
27814	Hexagon Nut M8 Din934 A2 for 50005	5100	35403	Plastic Check Nut PG 16 for 50005	9090	35413	Elbow 1/4" Int Brass for 50005	9200
35394	Control 03-Turbovac Tested for 50005	9010	35404	Cover Control Box for 50005	9100	35414	Hose Pillar 1/4x4 BU R Norma for 50005	9210
35395	Control Turbovac Basic for 50005	9011	35571	Cross Recessed Raised Cheese Head Screw M3.5x10 for 50005	9110	35415	Plug Blac R5 for 50005	9310
35396	Packing Control + Glue-Layer for 50005	9020	35406	Cable Gland PG16 IP65 Plastic for 50005	9120	35416	Plug Blac R6 for 50005	9320
15780	Switch-Disconnecter Tripolar 25A Front for 50005	9040	35407	Sealing Washer 0-1/4 for 50005	9130	35417	Plug Blac R10 for 50005	9330
35398	Control Panel Holder Turbovac for 50005	9050	35408	Reducing Ring 1/4"x1/8" for 50005	9140	15712	Hydraulic Oil for 3-Phase Vacuum Pump (060510) for 50005	9400
35399	Upper Sticker Turbovac 03 for 50005	9051	27819	Square Hose Coupling 1/8"x6 Ext. for 50005	9150	35419	Sticker Tension + Warning for 50005	9420
35400	Packing Cover Control + Glue-Layer for 50005	9060	34998	Flat Washer M4 D9021 A2 Carriage Ring M4 for 50005	9160	27794	Sticker Machine Type for 50005	9430
30010	Brass Nut 1/4" for 50005	9070	35411	Hexagon Nut M4 Din934 A2 for 50005	9170	35223	Sticker 19x38 Yellow for 50005	9440
35402	Square Hose Coupling 1/8"x4 Ext. for 50005	9080	35579	Vacuum Meter 40mm for 50005	9190	35224	Sticker 98x65 Yellow for 50005	9450